



## Durabelt® DX Pre-waxed Treadmill Belt Life-Extension Tips

**Notice:** The running deck must be replaced or flipped to an unused surface when installing a new belt. Not doing so will void the belt warranty and may cause damage to treadmill electronics. One-Year warranty against manufacturing defects.

### A clean belt is a healthy belt

To get maximum life from your Durabelt® keep it clean and free of dirt. Here's how:

1. **Clean Deck and Belt:** Slide a towel under the middle of the belt from one side of the treadmill to the other. With the treadmill off, hold the edges of the towel and pull the towel toward the front roller, then pull down toward the back roller. Rotate the belt and repeat.
2. **Wipe Off:** from front to back, the residual particles on the right and left exposed sides of the deck
3. **Repeat** steps 1 and 2 with a clean towel until the most of the dirt is removed.

All Durabelt® DX belts are maintenance free. No additional lubrication is needed for duration of the belt's 1 year warranty.

After one year, you can keep belt friction low and extend the life of your belt by using WaxBlast® every 2000 miles of use. Here's how to apply it:



WaxBlast®

1. **Squirt on the powdered wax:** With one hand, lift the belt on the left front side of the treadmill (about 12 " behind the cover) and with your other hand apply one squirt of powder wax between the belt and deck. Direct the spray towards the middle center of the deck. Repeat on the remaining 3 corners
2. **Walk the wax in:** Start the treadmill at 1 mph and walk on all surfaces of the deck for two minutes to make sure the wax is distributed evenly
3. **Clean up:** Wax Blast® wax powder is very slippery. Make sure no wax is left on the treadmill belt, the left and right deck channels or on the ground. Clean up excess wax with a damp rag.