

Life Fitness Cross-Trainers 90X, 93X, 95Xe, and 95Xi

How To... Replace the Resistors

Special Service Tools Required: NONE

1. Remove the Main Shrouds. See "How To..." in this section.
2. Remove the Lower Shroud Panels. See "How To..." in this section.
3. Disconnect the wires from the Resistors by removing the screws securing the wires to the Resistors. Mark the proper terminal point for proper reassembly.
4. Remove the Resistor Mounting Rods securing the Resistors to the Drive Module.
5. Install the new Resistors in reverse order .

Note: Make sure that the wires are properly installed.

