Life Fitness 9100 Series Heart Rate and Telemetry Equipped Treadmills TROUBLESHOOTING GUIDE

Symptom: Display reads "Notify Maintenance Lift Control Error"

Malfunction	Probable Cause	Corrective Action
Lift Error	Unit intermittently stuck in up position	 Press 9-1-9 ENTER, press INCLINE down button. Check all connections on CPU control board, check for presence of suppresser board. Replace CPU control board and suppresser board.
	Jammed in up position, 3 amp breaker popped	 □ Check 3 amp breaker. □ Check all connections, replace CPU board and suppresser board. □ Reset 3 amp breaker. □ Press 9-1-9 ENTER, press INCLINE down button.
	Unit will not lift, 3 amp breaker popped	 Check all connections on CPU control board, check suppresser board. Check home switch for smooth operation and check home switch cables/connections. Replace if necessary. Re-test.
	Incline control error.	☐ Press 9-1-9 ENTER, perform IA test procedure (two person test)
	Insufficient power source.	□ Verify power is a dedicated outlet. To verify, turn breaker at panel to off. Using a voltmeter, take a voltage reading at electrical outlet. With breaker off, zero volts should be detected.
		☐ If voltage is present at electrical outlet, line is not wired for dedicated service.
	Woight limitation	☐ Plug treadmill into a dedicated 120v, 20amp circuit. (See Operation Manual)
	Weight limitation. Will not lift. 3amp circuit breaker popped.	☐ Advise user of weight limit.
		Perform IA test procedure. Check home switch for smooth operation and check home switch cables/ connectors.
		☐ Check lift actuator cable connections and presence of (1 only) suppresser board.
		☐ Test circuit breakers. Replace if necessary.
	Failed, damaged or cracked lift actuator.	☐ Replace lift actuator.
		Call Life Fitness Customer Support Services 847-451-0036 or 1-800-351-3737

^{*}All treadmills require a 120v 20amp dedicated line.