

Troubleshooting No UB Movement / Actuator Movement

No Upper Body Arm Movement Flowchart

SOLUTIONS:

A1
Recalibrate UB Arms
Note: If problem still exist refer to "A7" solution

A2
Replace Replace Actuator

A3
Replace Battery

A4
Replace Battery Cable

A5
Replace UB Board
Note: S2 switch commands the actuator to move in upward direction. S1 directs the actuator to move in downward direction.
Note: If DS3 or DS4 LED light up only for a brief second when holding the switch (S1/ S2) the UB board is sensing voltage, so the UB Board do not need to be replaced. Possible the actuator is already maximized in it's position your are directing it to move to or something is causing UB system to bind.


A6
Replace Fuse (7amp 2AG fast blow)

A7
Replace actuator if it's not rotating smoothly or the speed moves much slower than normal.
Note: Compare speed and actuator rotation with another unit to check normality.

A8
Check female pins on data cable for too much space (See Photo Below)
Note: Make sure the female pins that connects to the display electronics and the LCB are completely closed before performing next step.

A9
Replace LCB
Note: Must Recalibrate UB arms after replacing LCB.

A10
Problem Resolved
Note: Recalibrate UB arms for best results.



Troubleshooting No UB Movement / Actuator Movement (cont)

No Upper Body Arm Movement Flowchart

SOLUTIONS:

A1
Recalibrate UB Arms
A2
Replace Replace Actuator
A3
Replace Battery
A4
Replace Battery Cable
A5
Replace UB Board

Note: S2 switch commands the actuator to move in upward direction. S1 directs the actuator to move in downward direction.

Note: If DS3 or DS4 LED light up only for a brief second when holding the switch (S1/ S2) the UB board is sensing voltage, so the UB Board do not need to be replaced. Possible the actuator is already maximized in it's position your are directing it to move to or something is causing UB system to bind.

A6
Replace Fuse (7amp 2AG fast blow)
A7
Replace actuator if it's not rotating smoothly or the speed moves much slower than normal.

Note: Compare speed and actuator rotation with another unit to check normality.

A8
Check female pins on dada cable for too much space (See Photo Below)


Note: Make sure the female pins that connects to the display electronics and the LCB are completely closed before performing next step.

A9
Replace LCB

Note: Must Recalibrate UB arms after replacing LCB.

A10
Problem Resolved

Note: Recalibrate UB arms for best results.



Troubleshooting No UB Movement / Actuator Movement (cont)

No Upper Body Arm Movement Flowchart

SOLUTIONS:

A1
Recalibrate UB Arms

A2
Replace Replace Actuator

A3
Replace Battery

A4
Replace Battery Cable

A5
Replace UB Board

Note: S2 switch commands the actuator to move in upward direction. S1 directs the actuator to move in downward direction.

Note: If DS3 or DS4 LED light up only for a brief second when holding the switch (S1/S2) the UB board is sensing voltage, so the UB Board do not need to be replaced. Possible the actuator is already maximized in it's position your are directing it to move to or something is causing UB system to bind.

A6
Replace Fuse (7amp 2AG fast blow)

A7
Replace actuator if it's not rotating smoothly or the speed moves much slower than normal.

Note: Compare speed and actuator rotation with another unit to check normality.

A8
Check female pins on dada cable for too much space (See Photo Below)


Note: Make sure the female pins that connects to the display electronics and the LCB are completely closed before performing next step.

A9
Replace LCB

Note: Must Recalibrate UB arms after replacing LCB.

A10
Problem Resolved

Note: Recalibrate UB arms for best results.



Troubleshooting No UB Movement / Actuator Movement (cont)

No Upper Body Arm Movement Flowchart

SOLUTIONS:

A1
Recalibrate UB Arms

A2
Replace Replace Actuator

A3
Replace Battery

A4
Replace Battery Cable

A5
Replace UB Board

Note: S2 switch commands the actuator to move in upward direction. S1 directs the actuator to move in downward direction.

Note: If DS3 or DS4 LED light up only for a brief second when holding the switch (S1/S2) the UB board is sensing voltage, so the UB Board do not need to be replaced. Possible the actuator is already maximized in it's position your are directing it to move to or something is causing UB system to bind.

A6
Replace Fuse (7amp 2AG fast blow)

A7
Replace actuator if it's not rotating smoothly or the speed moves much slower than normal.

Note: Compare speed and actuator rotation with another unit to check normality.

A8
Check female pins on dada cable for too much space (See Photo Below)



Note: Make sure the female pins that connects to the display electronics and the LCB are completely closed before performing next step.

A9
Replace LCB

Note: Must Recalibrate UB arms after replacing LCB.

A10
Problem Resolved

Note: Recalibrate UB arms for best results.




Key Not Responding or Key Down

- Engage Maintenance Mode
- Perform Display Test
- Perform Keypad Test
 - Determine which keypad is damaged
 - Keypad overlay
- UB Keypad (only on CT Elite) – Key Down 22-25 error



Troubleshooting Heart Rate


- Perform Heart Rate Test
 - As illustrated earlier
- If Heart Rate Test Fails
 - Take continuity on the contact grips




- Check heart rate board
 - Make sure wires are plugged in
- Clean Grips
- Disable telemetry board

Troubleshooting Banging and/or Scraping Metallic Noise


Banging and/or Scraping Metallic Noise



Troubleshooting Grinding Noise




Troubleshooting Pedal Knocking Noises




Troubleshooting Creaking and/or Squeaking and/or High Pitch Squeaking Noises

Creaking and/or Squeaking and/or High Pitch Squeaking Noises




Troubleshooting Scraping and/or Popping and/or Rubbing and/or Plastic Scraping

Scraping and/or Popping and/or Rubbing and/or Plastic Scraping



Troubleshooting Pinging Noises


Pinging Noises



Troubleshooting Grinding Brake

- Noise can come from bearings inside the brake
 - Inspect the pulley for brake dust
 - Inspect the pulley for looseness

Generator/Brake Assy



- Spin the brake free of the belt for bearing noise
 - If any of the above is true, replace the brake

Notes:

Troubleshooting Start Striding

START STRIDING PROMPT

SOLUTIONS:

A1

Possible user error

Note: The user must stride faster than 50 strides per minute. If error is intermittent possible the data cable has loose connection to display electronics or LCB.

A2

Connect wires and retest


A3

Close Female

Note: using a fine pointed object close the female pins shut so the two sides touch each other.

A4

Replace LCB



Troubleshooting Start Striding (cont)

START STRIDING PROMPT

SOLUTIONS:

A1

Possible user error

Note: The user must stride faster than 50 strides per minute. If error is intermittent possible the data cable has loose connection to display electronics or LCB.

A2

Connect wires and retest


A3

Close Female

Note: using a fine pointed object close the female pins shut so the two sides touch each other.

A4

Replace LCB



Troubleshooting Slipping

- Verify the belt tension
 - Drive belt
- Check the 3 idler pulley screws
 - Tighten down if necessary
- Check for wobble in the idler pulley
- Check for damaged or worn break belt

Troubleshooting Display Power Always On


- Power won't turn off
 - Turn wall voltage OFF if no AC Adapter is present



Notes:

UPLOADING SOFTWARE


- Use this software to correct any of these issues:
 - Corrected fitlinxx issue that causes display to reset during workout
 - Added feature to turn fan on automatically after the first minute of use
 - Corrected Katakana Translation in one message
 - Added code to prevent false Key Down error in idle and workout modes
 - Added code to allow fast scroll using the "+" and "-" keys when entering workout parameters
- Hardware required
 - FISP Loader
 - FISP Ribbon Cable
 - FISP Battery Pack
 - Serial Cable
- Time
 - 10 mins
- Software Required
 - [FISP Loader Program](#)



- Software Required
 - FISP Software
 - Software for CT
 - [Disp. Ver. 2.40 / 1.76](#)


● Installing the FISP Loader Software into the Computer

- **Note:** Create a file folder on your computer
 - C:\AVRISP\
- Unzip the FispLoader.zip




● Loading Primary Software into FISP Loader

- Make sure the battery pack is providing 6 V DC
- Connect Serial Cable to the computer and to the FISP




- Attach one end of the ribbon cable to the FISP device and the other end to the battery pack
- Verify that the FISP device is on
 - Solid orange LED on the FISP device




- Run the FISP.exe
- the **Load Fisp** buttons should now be enabled
 - After about 30 seconds

● **Setting up the Uploaders**

- Under **Device** dropdown box (left side), find and select Mega128




- Under **Flash FileName**, click on the white blank box
 - Change the directory to location of the software file
 - Select the **.a90** file for the Primary MCU




- Under **Device** click on **Options**:
- Verify that no lock bits are checked

Notes:

- Click on the Fuse Bits Tab
 - Verify that only the BODEN and BODLEVEL options are checked




- Click on the Fuse Bits High Tab
 - Verify that only CKOPT, JTAG, BOOTSZ0 and BOOTSZ1 Fuse options are checked




- Click on the **Load Fisp**
 - Start loading the program from the computer to the FISP device
 - It takes approximately 90 seconds
- Click the **CLOSE** button on the pop-up window
 - Remove power to the display
- Remove the serial cable from the FISP

● Loading Secondary Software into FISP Loader


- Make sure the battery pack is providing 6 VDC
- Connect Serial Cable to the computer and to the FISP




- Attach one end of the ribbon cable to the FISP device and the other end to the battery pack
- Verify that the FISP device is on
 - Solid orange LED on the FISP device




- Run the FISP.exe
- the **Load Fisp** buttons should now be enabled
 - After about 30 seconds
- Under **Device** dropdown box (left side), find and select Mega128
- Under **Flash FileName**, click on the white blank box
 - Change the directory to location of the software file
 - Select the **.a90** file for the Secondary MCU



- Under **Device** click on **Options**:
 - Verify that no lock bits are checked
- Click on the Fuse Bits Tab
 - Verify that only the CKSEL0, CKSEL1, CKSEL2, CKSEL3, SUT0, BODEN and BODLEVEL options are checked



- Click on the Fuse Bits High Tab
 - Verify that only JTAG, BOOTSZ0 and BOOTSZ1 Fuse options are checked



Notes:

- Click on the **Load Fisp**
 - Start loading the program from the computer to the FISP device
 - It takes approximately 90 seconds
- Click the **CLOSE** button on the pop-up window
 - Remove power to the display
- Remove only the serial (RS-232) cable from the FISP device
 - The FISP device will now retain the MCU's program

● **Uploading Software**


● Tools required

- Software Uploader boxes
- Phillips head screwdriver



● Connecting the Primary Uploader

- Remove the back cover of the display board
- Using the Uploader labeled Primary
 - Connect the Uploader ribbon cable to Primary port J8




NOTE: IT IS VERY IMPORTANT TO ONLY CONNECT THE PRIMARY TO THE PRIMARY JACK. FAILURE TO THE DISPLAY WILL RESULT IF YOU CONNECT THE WRONG UPLOADER, UNPLUG IT IMMEDIATELY

Notes:

- Programming the Primary Software
 - Stride on the CT to power up
 - The programming will commence automatically
 - **Do not stop striding or the programming will stop and the display will be damaged**
 - The Orange LED on the Uploader device should be blinking for approximately 2 minutes
 - After the Uploader device has programmed
 - Either change the LED color to Green or Red according to the result:
 - Red LED means programming failed – Retry
 - Green LED means programming was successful – Stop Pedaling
 - Remove Uploader cable from the Primary port

- Connecting the Secondary Uploader
 - Connect the Secondary Uploader ribbon cable to Secondary port J10




NOTE: IT IS VERY IMPORTANT TO ONLY CONNECT THE SECONDARY TO THE SECONDARY JACK. FAILURE TO THE DISPLAY WILL RESULT IF YOU CONNECT THE WRONG UPLOADER, UNPLUG IT IMMEDIATELY

- Programming the Secondary Software
 - Stride on the CT to power up
 - The programming will commence automatically
 - **Do not stop striding or the programming will stop and the display will be damaged**
 - The Orange LED on the Uploader device should be blinking for approximately 2 minutes
 - After the Uploader device has programmed
 - Either change the LED color to Green or Red according to the result:
 - Red LED means programming failed – Retry
 - Green LED means programming was successful – Stop Pedaling
 - Remove Uploader cable from the Secondary port

Notes:

- Display Initialization
 - Power up the CT
 - Enter Maintenance Mode
 - Press ‘1’, ‘4’ and ‘7’ at the same time to INIT
 - “INIT VARIABLES” should be displayed and all display parameters are reset




- Press  to save and EXIT

- Verifying the software versions and Model Settings
 - Let it rest for a few seconds then power up again
 - Enter Maintenance Mode
 - Verify the DISP VERS1 and DISP VERS2 match the new versions uploaded



- **Important:**
 - Scroll to Model to verify settings
 - PB-UB = Pro Bike, Upright
 - PB-RB = Pro Bike, recumbent
 - Pro CT = Pro CrossTrainer
 - Elite CT= Elite CrossTrainer
 - Stepper = Pro Stepper

- If the product is the CrossTrainer Elite the Upper body calibration should be performed

- Press the SCROLL key to select UB Calibration
- Press OK
- Press 2 Auto Calibration
 - The upper body arms will move up then down to calibrate the positions
- Press  to save and EXIT



Notes:



SERVICE MANUAL