Kit No. 610AK020

NOTE: This instruction sheet describes how to install the foot plate wave washers on the Arc Trainer 600A/610A.

Tools Required

- 3/16" Allen wrench
- 1. Read and understand all instructions thoroughly before installing this kit.
- 2. Verify you received the following:
 - A. Wave washer (4), HS427100
 - B. Loctite YA000201
- 3. Remove (right) foot plate assembly.
 - **A.** Turn the main power switch above the power inlet to the off (0) position.
 - **B.** Using a 3/16" Allen wrench, remove the two SHCS securing the (right) foot plate.
 - C. Remove flat washers and foot plate. *NOTE: Do not remove spacer.*
 - D. Repeat steps 3B-3C for left foot plate

4. Install (right) foot plate assembly.

- **A.** Install one wave washer (A) onto each foot plate shaft as shown in Figure 1.
- **B.** Slide the foot plate onto the foot plate shaft.
- **C.** Place a drop of loctite (B) on one of the SHCS. Place another drop of loctite in the shaft (where the SHCS will be tightened into).
- **D.** Install flat washers and SHSC (removed in steps 3B and 3C) and securely tighten.

- Installation Instructions
- **E.** Repeat steps 4C and 4D for installing the other flat washer and SHCS.
- F. Repeat steps 4A-4E for left foot plate.




Figure 1 (right foot assembly)

- **G.** Turn the main power switch to the on (I) position.
- **H.** Test the unit to verify proper operation.



 $\mathsf{Cybex}^{\textcircled{R}}$ and the Cybex logo are registered trademarks of Cybex International, Inc. Arc Trainer^{\textcircled{R}} and its mark are registered trademarks of Cybex International, Inc.

10 Trotter Drive Medway, MA 02053 • 508-533-4300 • FAX 508-533-5183 • www.cybexinternational.com • techhelp@cybexintl.com techpubs@cybexintl.com • Copyright © 2008, Cybex International, Inc. All rights reserved • 610A-405 A • March 2008