



Part Replacement Procedure

Pedal Replacment – Pro Bike (6000 Series)



Loosen Right



Tighten Right



Loosen Left



Tighten Left

To replace the pedals on a Pro Bike, you will need the following:

- 14 mm pedal wrench
- set of pedals (part number 800-4009)

Removing Pedals

1. Using the pedal wrench, remove the right pedal by turning the wrench counter-clockwise
2. Using the pedal wrench, remove the left pedal by turning the wrench clockwise.

Install Pedals

Note: It is best to hand-thread the pedals before using the wrench to reduce the possibility of cross-threading. Use the pedal wrench to tighten completely.

1. Install the right pedal by turning clockwise. Note: The right pedal will have an R on the underside.



2. Install the left pedal by turning counter-clockwise. Note: The left pedal will have an L on the underside.



Once the new pedals have been installed, test for proper operation.