


# CHAIN REPLACEMENT - MODEL C,D,E

0607




concept2.com



1.



2.



3.



4.




5.



6.



# CHAIN REPLACEMENT - MODEL C,D,E



7.




8.




9.

**Note:**  
 If your rower has a wooden handle, follow steps 10-14.  
 If your rower has a plastic handle, follow steps 15-17.


Wooden Handle




10.



11.



12. Remove old chain and replace with new chain.





13.



14. Proceed to step 18.

# CHAIN REPLACEMENT - MODEL C,D,E



# CHAIN REPLACEMENT - MODEL C,D,E

23.



24.



25.



26.

