

Multi-Jungle Stations Guide

MJCORE (MJCORE-STA)



MJAP (MJAP-STA)



MJTP (MJTP-STA)



MJHAR



MJLP (MJLP-STA)



MJLPD (MJPD-STA)



MJRW (MJRW-STA)



MJRWD (MJRW-STA)



MJAXO (MJAXO-STA)



MJACO (MJACO-STA)



MJBLNKSHRD

- This is an empty station with a shroud.

MJBLANK

- This is an empty station with nothing at all.

NOTE:

- All stations can be ordered separately by adding “-STA” to the station code.
- Example: MJAXO station only (no core) would be MJAXO-STA and includes the weight stacks.

How to convert MJ5 to and MJ8:

- Order MJ4 with any 3 new stations. The fourth station has to be MJBLANK.
- Need to order P/N MJAXO Boom/Part Number 76418xx (in the correct frame color) and the Hardware Kit/Part Number 8062001 thru service.
- Discard the old 5th stack tower.