


NGS Schematics



Precor EFX 544 Drive Assembly



Drive Assembly

8	PRX10248-107	Washer, wave	57	PRX10003-152	Allen Head Bolt
9	PRX10241-105	Washer, thrust	59	PRX10141-107	Hex Head Screw
10	PRX10005-157	Cover Screw	60	PRX11211-102	Leveler
21	PRX50528-106	Flywheel, 544, pin not included	61	PRX10133-115	Snap Ring
22	PRX10008-102	Lock Nut	62	PRX50523-106	Assembly Front Cover
30	PRX10016-108	Screw	63	PRX10139-137	Machine Screw, stainless steel
31	PRX37549-101	End Cap, ramp	68	PRX10220-108	Key, for flywheel
32	PRX50534-102	Ramp Assembly, w/end cap	70	PRX11332-101	Washer
33	PRX10248-108	Wave Washer	72	PRX37828-101	Bushing, for flywheel
34	PRX10249-105	Washer, stainless steel	73	PRX10561-109	Drive Belt, poly V
35	PRX50532-108	Assembly, wheel	74	PRX50517-108	Pulley Assembly, w/shaft, 544
42	PRX10008-110	Lock Nut	64	PRX31074-101	Foot, molded plastic
52	PRX34063-101	End Cap	76	PRX50519-106	Rear Cover Assembly