


CHAIN REPLACEMENT - MODEL C,D,E

0607




concept2.com



1.



2.




3.



4.




5.



6.



CHAIN REPLACEMENT - MODEL C,D,E



7.




8.




9.

Note:
 If your rower has a wooden handle, follow steps 10-14.
 If your rower has a plastic handle, follow steps 15-17.


Wooden Handle




10.




11.



12. Remove old chain and replace with new chain.





13.



14. Proceed to step 18.

CHAIN REPLACEMENT - MODEL C,D,E



CHAIN REPLACEMENT - MODEL C,D,E

23.



24.



25.



26.

