


CHAIN REPLACEMENT - MODEL C,D,E

0607




concept2.com



1.



2.




3.



4.




5.







6.





CHAIN REPLACEMENT - MODEL C,D,E



Note:
If your rower has a wooden handle, follow steps 10-14.
If your rower has a plastic handle, follow steps 15-17.



CHAIN REPLACEMENT - MODEL C,D,E



CHAIN REPLACEMENT - MODEL C,D,E

23.



24.



25.



26.

