

# Cybex 625T Treadmill

## Error code list

Error Code	Description
Error 1	Drive did not start (No Speed at Startup)
Error 2	GFX Communications issue
Error 3	Speed Irregularity / Underspeed
Error 4	Upper Display Communications issue
Error 5	Drive Communication Issue
Error 6	Membrane Fault (stuck key)
Error 7	Controller Over-Current (Fold-back)
Error 8	Approaching Over-Temperature
Error 9	MCC Watchdog Triggered
Error 10	Motion Sensor Blocked
Error 11	Motion Sensor Defective
Error 12	Graphics Board Watchdog Triggered

## Cybex 625T Treadmill

Error 14	Drive Error Unknown
Error 15	Embedded A/V Device Failure
Error 16	Membrane Fault (No Membrane)
Error 18	Membrane Fault - Stuck Thumb Control
Error 19	Drive Enable Line is open
Error 92	Over Current (Output)
Error 93	Over Voltage (DC Link)
Error 94	Over Heat (Heatsink)
Error 95	Low Voltage (DC Link)
Error 96	Thermal Integrator of output current
Error 98	Display Communication Lost – Belt speed zero
Error 99	Display Communication Lost – Belt moving
Error 103	Input Current OC trip (Drives with PFC only)

## Cybex 625T Treadmill

Error 140	Cannot find home position on power-up
Error 141	Cannot find home position during use
Error 142	Out of incline range (over 15% or lower than -3%)
Error 150	Out of Speed Range (over 150 Hz)
SVC	Belt and Deck service odometer