

GZFI8028.0

Key	Part Number	Description	Qty.
1	GZ5674	FRAME	1
2	GZ5676	LEFT ARM	1
3	GZ5675	RIGHT ARM	1
4	GZ5578	TOWER	1
5	GZ3248-03	GUIDE ROD	2
6	GZ1678	WEIGHT BUMPER	2
7	GZ30599	20-POUND PTATE	9
8	GZ30598	10-POUND PLATE	11
9	GZ1391-01	WEIGHT INSERT	41
10	GZ5486	WEIGHT ROD	1
11	GZ1673	SET SCREW	4
12	GZ1020	GUIDE BUSHING	2
13	GZ4392	TOP WEIGHT	1
14	GZ1754	WEIGHT PIN	1
15	GZ1517	TOWER FOOT	4
16	GZ1504	TRIM	2
17	GZ30349	LONG TOWER PLATE	1
18	GZ30347	SHORT TOWER PLATE	1
19	GZ1084	GUIDE ROD NUT	4
20	GZ3516	COVER	1
21	GZ1085	GUIDE ROD WASHER	4
22	GZ30218	ANCHOR STRAP	1
23	GZ3453	TOWER CAP	1
24	GZ1730	STRAIGHT HANDGRIP	2
25	GZ1758	HANDLE COLLAR	4
26	GZ1757	HANDLE ENDCAP	4
27	GZ1011-01	1" BEARING	4
28	GZ3575	POTTEY PLATE	2
29	GZ3523	COUNTER WEIGHT	2
30	GZ4186	"U"-BRACKET	1
31	GZ1003-08	PULLEY	5
32	GZ1003-02	PULLEY W/O BUSHING	2
33	GZ3102	CABLE GUARD	3
34	GZ1530	PIVOT ROD	1
35	GZ1018-07	1" SNAP RING	2
36	GZ2311	THIGH POST	1
37	GZ1025	SLIDE PLATE	4
38	GZ1067	ALUMINUM SPACER	4
39	GZ3079	THIGH PLATE	2
40	GZ5108-02	THIGH PAD	2
41	GZ5108-01	BENCH PAD	1
42	GZ1730	CURVED HANDGRIP	2
43	174796	1/4" X 1" BUTTON BOIT	2
44	GZ1486	FRAME FOOT	2
45	GZ1501	POP PIN	1
46	GZ5020-09	ARM CABLE	1
47	GZ5020-52	TOWER CABLE	1
48	GZ1418	ROD NUT	1
49	GZ1419	STAR WASHER	1
50	GZ1431	ROD WASHER	1
51	GZ1430	WINGNUT	2
52	167082	17MM SNAP RING	2
53	GZ1007	3/8" NYLON LOCKNUT	11
54	GZ1069	SERRATED WASHER	9
55	GZ1052	PIVOT WASHER	4
56	GZ1013-02	3/8" X 1 3/4" BOLT	1
57	GZ1013-11	3/8"X 4 1/2" BOLT	4
58	GZ1074	5/16" WASHER	4
59	GZ1013-12	3/8" X 1 1/4" BOLT	6

60	GZ1761	#10 X 1/8" SET SCREW	16
61	GZ1111	ARM BUMPER	2
62	GZ1012-07	3/8" X 1/2" BUTTON SCREW	12
63	GZ1038-04	3/8" X 1" FLATHEAD BOLT	4
64	GZ1013-01	3/8" X 3/4" BOLT	2
65	GZ1013-04	3/8" X 2" BOLT	3
66	GZ1014-01	3/8" X 1" NON-PATCH BOLT	2
67	GZ1009-03	1/2" X 1 1/4" BOIL	2
68	GZ1013-21	3/8" X 6" BOLT	1
69	GZ1565	LONG PLATE FRAME	1
70	GZ1567	SHORT PLATE FRAME	1
71	GZ1435	TEFLON TAPE	3
72	GZ1353	COUPLER COVER	1
73	GZ1021-01	RIVET	12
74	GZ1083	3/8" FINE THREAD NUT	1
75	GZ1381	1/4" X 2" ROLL PIN	1
76	GZ1013-03	3/8" X 1" BOLT	2
77	GZ9434	LONG WEAR COVER	2
78	GZ9433	SHORT WEAR COVER	1
79	GZ30828	ACCESS PANEL	1
80	GZ1751	ACCESS PANEL GASKET	1
81	192770	1/4" X 3/4" BOLL	6
82	GZ1735	1/4" CAGE NUT	6
83	GZ5124-11	SEAT WEAR COVER	1
	0	NON-ILLUSTRATED PARTS	0
		WHAT PART IS NEEDED?	
#	GZ7415	USER'S MANUAL	1
#	GZ7415FR	USER'S MANUAL	1
#	GZ7415G	USER'S MANUAL	1
#	GZ7415IT	USER'S MANUAL	1
#	GZ7415SP	USER'S MANUAL	1
		WHAT PART IS NEEDED?	
#	GZ7003	DECAL, WARNING	1
#	GZ7003FR	DECAL, WARNING	1
#	GZ7003G	DECAL, WARNING	1
#	GZ7003IT	DECAL, WARNING	1
#	GZ7003SP	DECAL, WARNING	1
		WHAT PART IS NEEDED?	
#	GZ7005	DECAL,MOVING PARTS	1
#	GZ7005FR	DECAL,MOVING PARTS	1
#	GZ7005G	DECAL,MOVING PARTS	1
#	GZ7005IT	DECAL,MOVING PARTS	1
#	GZ7005SP	DECAL,MOVING PARTS	1
		WHAT PART IS NEEDED?	
#	GZ7026	DECAL,SELECTOR PIN INSERT	1
#	GZ7026FR	DECAL,SELECTOR PIN INSERT	1
#	GZ7026G	DECAL,SELECTOR PIN INSERT	1
#	GZ7026IT	DECAL,SELECTOR PIN INSERT	1
#	GZ7026SP	DECAL,SELECTOR PIN INSERT	1
		WHAT PART IS NEEDED?	
#	208842	DECAL, KEEP CLEAR	1
#	GZ7274FR	DECAL, KEEP CLEAR	1
#	GZ7274G	DECAL, KEEP CLEAR	1
#	GZ7274IT	DECAL, KEEP CLEAR	1
#	GZ7274SP	DECAL, KEEP CLEAR	1

EXPLODED DRAWING—Model No. GZFI8028.0

R1207A

