

**GZFM6003.3**

Key	Part Number	Description	Qty
	0	FREE MOTION TRICEP	0
	0	5/03 SMITHFIELD	0
	0	COMPANY 14	0
1	GZ5067	TOWER	1
2	GZ4549-01	ACCESS COVER	1
3	GZ5008	SEAT FRAME	1
4	GZ5108-01	SEAT	1
5	GZ1021-01	RIVET	24
6	GZ5006	LEFT STABILIZER	1
7	GZ5005	RIGHT STABILIZER	1
8	GZ1018-01	1" RETAINER RING	2
9	GZ1050	1" WASHER	2
10	GZ1014-05	3/8" X 2.25" BOLT	1
11	GZ3190-02	RIGHT STABILIZER COVER	1
12	GZ3190-01	LEFT STABILIZER COVER	1
13	GZ3091	DOUBLE CABLE GUIDE	1
14	GZ3102	SINGLE CABLE GUIDE	4
15	GZ1003-01	PULLEY	5
16	GZ3196	SEAT FRAME COVER	1
17	GZ1193	TOP WEIGHT BUMPER	1
18	GZ5001-01	SWIVEL ARM	2
19	GZ1049	1" WAVE WASHER	2
20	GZ1011-01	PIVOT PULLEY BEARING	4
21	GZ3053	TRUNNION	2
22	GZ1517	FLOOR BUMPER	3
23	GZ1069	3/8" SERRATED LOCK WASHER	2
24	GZ1009-01	1/2" X 1" BOLT	8
25	GZ1001	WEIGHT BUMPER	2
26	GZ1656	WEIGHT PIN	1
27	GZ3072-02	LARGE WEIGHT	10
28	GZ3072-01	SMALL WEIGHT	9
29	GZ5009	TOP WEIGHT	1
30	GZ3248-02	WEIGHT GUIDE ROD	2
31	GZ1020	WEIGHT GUIDE BUSHING	2
32	GZ5109-12	HANDLE W/STRAP	2
33	GZ1084	5/8" NUT	4
34	GZ1018-03	1 1/8" RETAINER RING	2
35	GZ1070	EYEBOLT	2
36	GZ1075	3/8" JAM NUT	4
37	GZ1011-02	CABLE BEARING	2
38	GZ3238	ALUMINUM COUPLER	2
39	GZ1047	CABLE SET SCREW	8
40	GZ1062	RUBBER COVER	2
41	GZ3052-04	CABLE	1
42	GZ1013-02	3/8" X 1.75" BOLT	2
43	GZ1007	3/8" NUT	5
44	GZ1085	5/8" LOCK WASHER	4
45	GZ1009-04	1/2" X 4.5" BOLT	2
46	GZ3192-02	RIGHT TOWER COVER	1
47	GZ1013-04	3/8" X 2" BOLT	2
48	GZ1024	TOP WEIGHT BUSHING	1
49	GZ1080	SPRING CLIP	2
50	GZ1012-07	3/8" X 1/2" SCREW	12
51	GZ1014-01	3/8" X 1" SCREW	2
52	GZ3192-01	LEFT TOWER COVER	1
53	GZ1097	ROLL PIN	4
0	0	NON-ILLUSTRATED PARTS	0
		<b>WHAT PART IS NEEDED?</b>	

#	GZ7003	DECAL, WARNING	1
#	GZ7003FR	DECAL, WARNING	1
#	GZ7003G	DECAL, WARNING	1
#	GZ7003IT	DECAL, WARNING	1
#	GZ7003SP	DECAL, WARNING	1
#	GZ7004	INTERNAL WARNING DECAL	1
		<b>WHAT PART IS NEEDED?</b>	
#	GZ7005	DECAL, MOVING PARTS	1
#	GZ7005FR	DECAL, MOVING PARTS	1
#	GZ7005G	DECAL, MOVING PARTS	1
#	GZ7005IT	DECAL, MOVING PARTS	1
#	GZ7005SP	DECAL, MOVING PARTS	1
		<b>WHAT PART IS NEEDED?</b>	
#	GZ7006	CAUTION DO NOT USE DECAL	1
#	GZ7006FR	CAUTION DO NOT USE DECAL	1
#	GZ7006G	CAUTION DO NOT USE DECAL	1
#	GZ7006IT	CAUTION DO NOT USE DECAL	1
#	GZ7006SP	CAUTION DO NOT USE DECAL	1
		<b>WHAT PART IS NEEDED?</b>	
#	GZ7026	DECAL,SELECTOR PIN INSERT	1
#	GZ7026FR	DECAL,SELECTOR PIN INSERT	1
#	GZ7026G	DECAL,SELECTOR PIN INSERT	1
#	GZ7026IT	DECAL,SELECTOR PIN INSERT	1
#	GZ7026SP	DECAL,SELECTOR PIN INSERT	1
#	156809	BAG WARNING DECAL	2
		<b>WHAT PART IS NEEDED?</b>	
#	GZ7214	USER'S MANUAL	1
#	GZ7214FR	USER'S MANUAL	1
#	GZ7214G	USER'S MANUAL	1
#	GZ7214IT	USER'S MANUAL	1
#	GZ7214SP	USER'S MANUAL	1

# EXPLODED DRAWING—Model No. GZFM60033

R0204A

