

Life Fitness Cross-Trainers 90X, 93X, 95Xe, and 95Xi
How To... Replace the Reed Switch Cable Assembly

Special Service Tools Required: NONE

1. Remove the Main Shrouds. See “How To...” in this section.
2. Disconnect the Reed Switch Cable from the Power Control Board.
3. Remove the two screws securing the Reed Switch to the Drive Module.
4. Install the new Reed Switch Cable Assembly in reverse order.

