## Life Fitness Cross-Trainers 90X, 93X, 95Xe, and 95Xi How To... Replace the Outer Link Cover

Special Service Tools Required: NONE

- 1. Remove the Main Shrouds. See "How To..." in this section.
- 2. Remove the six Phillips screws (three at the top, three at bottom) securing the Outer Link Cover to the Inner Link Cover.
- 3. Install the new Outer Link Cover in reverse order.

