

How To... Replace the Handlebars

Special Service Tools Required: NONE

1. Remove the Outside Deadshaft Covers.
See "How To..." in this section.
2. Remove three Allen bolts securing the Handlebar to the end of the Deadshaft. Disconnect the Heart Rate cable if present.
3. Install new Handlebar in reverse order. If the Heart Rate cable is present, use caution to prevent pinching the cable.

