



# Life Fitness Models 8500, 9100, and 9500HR Cross-Trainers

## How To... Replace the Display Console Support Assembly

**Tools required:** Phillips screwdriver and Allen wrench set



1. Remove the console and accessory tray. See "How To."
2. Remove the MONOCOLUMN COVER (ALL MODELS) and ROCKER ARM COVERS (9500).
3. Remove the POLAR RECEIVER.
4. Remove the two(2) HEX HEAD CAPSCREWS and FLAT WASHERS securing the CONSOLE SUPPORT ASSEMBLY.
5. Lift the CONSOLE POST out of the MONOCOLUMN while guiding the wire harness out.
6. Install new console support in reverse order.

