

Life Fitness Model 8500, 9100, and 9500HR Cross-Trainers How To... Replace the Display Console

Tools required: Phillips screwdriver

1. Remove the MOUNTING SCREWS(4) from under the CONSOLE.
2. Lift the console up enough to disconnect the 10-Pin and 3 or 4-Pin connectors.
3. Remove the console and spacer from the console post or if equipped, the accessory tray which is standard on CT95/91 and optional on CT85.
4. Install new console in reverse order.

