

Life Fitness Models X9i, 8500, 9100, and 9500HR Cross-Trainers

How To... Replace the Display Console and Accessory Tray

Tools required: Phillips screwdriver

1. Remove the (4) MOUNTING SCREWS from under the CONSOLE, Connecting the console to the post.
2. Lift the console up enough to disconnect the 16-pin and the 3-pin and 4-Pin connectors (on the CT9500).
3. Lift the console and remove.
4. If equipped, remove the accessory tray from the console. This is standard on CT95/91 and X9i and optional on CT85.
5. Install new console in reverse order.

