

Life Fitness Model 97Ti, 97Te, 95Ti, 95Te and 93T Arctic Silver Treadmills

TROUBLESHOOTING GUIDE

| SYMPTOM | PROBABLE CAUSE | CORRECTIVE ACTION |
|--|--|---|
| Display Reads: SMART STOP UNPLUGGED (95Ti and 97Ti are equipped) | Broken, damaged, or unplugged harness. | Reseat or replace smart stop harness. |
| Display Reads: CLOCK COMM BAD | Frame board or bad wire harness. See Diagnostic Test Frame Tag EEPROM. | Verify continuity on wire harness. If continuity exists, replace frame tag PCB. See How To... Replace Frame Tag PCB. If continuity does not exist, replace wire harness. |
| Display Reads: FRAME TAG UNPLUGGED | Disconnected wire harness. | Reconnect wire harness. |
| Display Reads: SCI ERROR | Bad wire harness connection. | Bad wire harness or noise. Reseat connection and verify operation. If problem exists, reconnect your connection at the display console to wax/lift PCB |
| Display Reads: DYNAMIC CURRENT TRIP | Motor Controller, striding belt or deck. | Perform belt and deck test in Diagnostic Section 2. |
| Display Reads: CHECKSUM ERROR XXXX | Display Console | Replace Display Console |
| Display Reads: NOTIFY MAINTENANCE MOTOR CONTROLLER COMM BAD ERROR | Motor Controller. | Overheated motor caused by worn or damaged belt and deck. See Belt and Deck Test in Diagnostic Sect 2. |