

**Life Fitness 9100 Series Heart Rate and Telemetry Equipped Treadmills
TROUBLESHOOTING GUIDE**

Symptom: Wax Is Leaking From Treadmill

Malfunction	Probable Cause	Corrective Action
<p>Wax Leak</p>	<p>Partially open or faulty fill valve.</p> <p>Loose hose connections.</p> <p>Faulty connection at "T" fitting and bag.</p> <p>Wax bag is torn.</p> <p>Wax pump does not shut off. Wax passes through pump and slowly drips from nozzle</p>	<p><input type="checkbox"/> Fully close fill valve.</p> <p><input type="checkbox"/> Inspect hose connections and secure as necessary.</p> <p><input type="checkbox"/> Replace if necessary.</p> <p><input type="checkbox"/> Replace wax bag and all tubing.</p> <p><input type="checkbox"/> Replace wax bag.</p> <p><input type="checkbox"/> Replace wax pump.</p> <p>Call Life Fitness Customer Support Services 847-451-0036 or 1-800-351-3737</p>