

**Life Fitness 9100 Series Heart Rate and Telemetry Equipped Treadmills
TROUBLESHOOTING GUIDE**

Symptom: Wax Will Not Fill Properly

SECTION I

Malfunction	Probable Cause	Corrective Action
<p>Wax will not fill</p>	<p>Fill valve in kit has crimped fill hose.</p> <p>Fill valve in treadmill is not fully open.</p> <p>Fill hose in treadmill is crimped.</p>	<ul style="list-style-type: none"> <input type="checkbox"/> Check the fill valve for proper operation. <input type="checkbox"/> Check the fill hose for kinks, straighten as necessary. <input type="checkbox"/> Check T-connector for blockage. <input type="checkbox"/> Check fill valve in treadmill for proper operation. <input type="checkbox"/> Check the fill hose for kinks, straighten as necessary. <input type="checkbox"/> Lightly squeeze wax container. <p>Call Life Fitness Customer Support Services 847-451-0036 or 1-800-351-3737</p>