SECTION III

Life Fitness 9100 Series Heartrate and Telemetry Equipped Treadmills How To...REMOVE AND REPLACE THE ANTI-SCUFF PADS

Tools Required: Pencil, non-abrasive cleaner, paper towels

Step 1

Use a pencil to draw an outline of the upper corners of the worn ANTI-SCUFF PAD on the FRAME.

Step 2

Peel the worn ANTI-SCUFF PAD from the FRAME and clean the residue with non-abrasive cleaning solution and paper towels.

Step 3

Peel the protective backing from the new ANTI-SCUFF PAD.

Step 4

Align the top two corners of the new ANTI-SCUFF PAD with the lines drawn in Step 1 and press in place.

NOTE: TO AVOID AIR BUBBLES, THE TOP TWO CORNERS MUST BE ALIGNED EXACTLY BEFORE PRESSING DOWN THE ENTIRE ANTI-SCUFF PAD.

Step 5

Press the remainder of the new ANTI-SCUFF PAD against the FRAME SIDE PANEL. Start at the top and apply even pressure downward to the bottom keeping an even distance to the edge of the STRIDING BELT.

NOTE; IN THE EVENT OF AIR BUBBLES, USE A SCRIBE TO MAKE A SMALL HOLE IN THE AIR BUBBLE, THEN PRESS THE PAD DOWN AGAINST THE FRAME PANEL UNTIL THE AIR BUBBLE IS GONE.