


Life Fitness Models 9100, 9500HR, 9700HR, and 9700HR w/Decline Treadmills
DIAGNOSTICS: INFORMATION – MAIN MOTOR INFO MODE



This area will allow the user to see the current information about the main motor and motor controller. The information will cover the following areas:

DISPLAYED INFORMATION

MOTOR MINUTES
 NUMBER OF POWER UP RESETS
 NUMBER OF HARDWARE CURRENT ERRORS
 NUMBER OF STATIC CURRENT TRIP
 NUMBER OF MAX TEMPERATURE TRIP
 NUMBER OF MAXIMUM VOLTAGE TRIP

NUMBER OF DYNAMIC CURRENT TRIP
 MAXIMUM STATIC CURRENT VALUE
 MAXIMUM TEMPERATURE VALUE
 MAXIMUM VOLTAGE VALUE
 MAXIMUM DYNAMIC CURRENT VALUE
 NUMBER OF SPEED SENSOR ERROR

The information will automatically scroll every 3 seconds or using any of the arrow keys will allow you to scroll through the main motor information.

Pressing the 'PAUSE' key can LOCK the display. This will prohibit the scrolling of the information. Press the 'CLEAR' key to exit the Main Motor Info and return to the System Info Menu.