



Bubble#	OEM Number	Description	Notes	
AN15	1000208238	Cover Console Back Printing EP	If replacing the console back, also send <b>1000228705</b> to be able to hide the controller wire.	
AN4	1000226659	Extrawork COVER OVERLAY PR EP612		
AN51	<b>1000208535</b>	Heart Rate Board Set SALUTRON 8600 EP93C		
N13	0000087056	Vent Fan ABS/PA-746 Pantone:877C TM501		
N151	008864-A	Screw Special Round 2.9x1.06Px7L(Hi-Lo)		
N152	008866-A	Screw Special Round 4.0x1.34Px12L(Hi-Lo)		
N153	005157-A	Washer Flat 4.3x12.0x1.0T Black Zinc		
N154	008865-B	Screw Special Round 2.9x1.06Px12L(Hi-Lo)		
N16	1000210553	USB EP90B		
N18	0000089261	Cover IPOD Fixing ABS/PA746 Deep Grey 80		Order this cover if a console uses an iPod cable. If the console's iPod cable has been removed, order the cover 00000 <b>93006</b> .
N202	0000092696	Fixing Plate Fan 0.8t T5x-02		
N203	0000095575	Tape Foam One-Sided 50x15x1.5T		
N22	1000216152	Fan ADJ Plate SUS304 0.3t T9000		
N25	1000212322	Shim Rubber D NBR BLACK TM507C		
N33	0000086064	Cover Console Right ABS/PA-746 BL TM501		
N34	0000086065	Cover Console Left ABS/PA-746 BL TM501		
N52	0000088790	Anti-Slippery Pad TPR+30%PP BL MX-E5XC-F		
N53	0000088791	TV Earphone Wire Cover ABS/PA746 80435	This is for a unit with no entertainment. It does not have a hole for the earphone jack. Order Overlay & Membrane together Target Heart Rate Overlay	
N61	<b>1000226707</b>	Documentation Overlay Program - English		
N62	<b>1000226665</b>	OVERLAY HEART RATE ZONE ENG EP612		
N62	<b>1000230083</b>	OVERLAY SET TV EP612 -		
N81	0000088743	Screw TRH M3x.5Px6L MT PH CST ZNC F-T		
N85	<b>1000228688</b>	SCREW BH M5X0.8PX12L PH BAN		
N97	0000083278	USB Cover USB-03		
N98	1000211294	Screw FH M3X0.5PX30L - PH BZN		

Not Shown	0000093006	Cover IPOD Fixing ABS/PA746 80435 MX-E5X	Per customer request. Note: Cover removes the options for iPod connectivity. To install, disconnect and remove iPod cable from console and conceal input with cover.
Not Shown	1000228299	MO WIFI WIRE EP90B/EP93C/CS14B -	WiFi Module
Not Shown	1000216927	WIFI Antenna 250(WPB105 MINI 1.13 2.4GHz	Just the antenna, no board.
Not Shown	1000230083	OVERLAY SET TV EP612 -	Entertainment-See Entertainment Master on TV product page
Not Shown	015267-AE	Fixing Plate Right TV	Entertainment-See Entertainment Master on TV product page
Not Shown	018141-AE	Fixing Plate TV Left	Entertainment-See Entertainment Master on TV product page
Not Shown	0000089506	TV Earphone Wire Cover ABS/PA746 80435	Entertainment-See Entertainment Master on TV product page
Not Shown	1000231589	SCREW BH M3X0.5PX6L CT PH SST BAN	Entertainment-See Entertainment Master on TV product page
Not Shown	1000348689	Earphone board U138A3/H001 EP621	Entertainment See Entertainment Master on TV product page. Only send this part if the customer has the upgraded, 9-pin connecting wire and the 4-pin connect board. See service bulletin "Earphone Board Update".
Not Shown	1000356740	Quickly Key Wire 200+250(TKP,H254M	Entertainment-See Entertainment Master on TV product page
Not Shown	1000210489	NETWORK SIGNAL EXTEND WIRE 900(TKP H6630	Entertainment-See Entertainment Master on TV product page
Not Shown	1000211037	WIRE NETWORK SIGNAL 1000(TKP H6630R1-08+	Entertainment-See Entertainment Master on TV product page
Not Shown	004762-00	Screw Hex Socket BH M8x1.25Px70L	Entertainment-See Entertainment Master on TV product page
Not Shown	004926-00	Nut Nylon M8x1.25P	Entertainment-See Entertainment Master on TV product page
Not Shown	005005-00	Washer Spring Lock 8.2x15.4x2.0t	Entertainment-See Entertainment Master on TV product page

Not Shown	004355-00	Screw Oval PH M4X0.7PX10L	Entertainment-See Entertainment Master on TV product page
Not Shown	022311-A	Pin Spring M3X10L	Entertainment-See Entertainment Master on TV product page
Not Shown	065248-A	TV Coax Adaptor Female F-A028-NBX7-C	Entertainment-See Entertainment Master on TV product page
Not Shown	<b>1000228042</b>	TV PWR EXT 900(H6630R1-04+DC 2.5x5.5	Entertainment-See Entertainment Master on TV product page
Not Shown	1000231122	E-PORT EXTENDED WIRE 350(##,3205615600 A	Entertainment-See Entertainment Master on TV product page
Not Shown	1000227270	E-PORT Wire - - 1000 (AMP,569532) CS20	Entertainment-See Entertainment Master on TV product page
P03	1000210330	Wire Connect USB 250(JST,XAP-06V-1)x2	
P32	1000206777	C Safe+TV Connect Wire 200(TKP H20J2-15x	
W04	0000095231	Control Board USB H001 U105A5 EP603	
W13	0000086684	Speaker Set AK-402808BC-3T+280+XAP-02 TM	
W27	1000231080	Wire Ipod 550(JST XADR-16+PAP-06/-10) T7	
W28	<b>1000353342</b>	Ipod Extend Wire 300(MF1512S0017+JA	Discontinued - Replaced with third generation cable
W28	<b>1000353342</b>	Ipod Extend Wire 300(MF1512S0017+JA	Third generation cable.
W44	0000092217	Heart Rate Power Wire 250L(2510A-03+XAP-	
W45	0000089849	Wire Hand Pulse Sensor 350L(2510A-06,TKP	
W47	1000232274	GND - - Yellow/Green1 I-POD 18AWG 200mm	
W51	<b>1000226708</b>	Control Board Console - H001 S001 CS19	
W52	<b>1000228705</b>	CONTROL BOARD C-SAFE U11AA2 H001 COATING	
W53	<b>1000229558</b>	Exchanged Board Console - H001 COATING -	
W56	061339-B	Fan DC12V/0.3A PMB1297PYB3-AY EP70	
W57	<b>1000208547</b>	Power Wire 200(JST VHR-3NX2) EP93C	
W58	<b>1000208539</b>	Wire QUICK CONNECT 200(HRS HIF3BA-20D-2.	
W63	<b>1000229835</b>	Membrane Keypad Programm - CS19	Order Overlay & Membrane together
W65	003383-A	Ferrite Choke FH0900B-2 Lian Ci TM38	
W66	<b>1000206779</b>	Console Cable 250(MOLEX,50-57-9408+MOLEX,	

W69	056225-A	Ferrite PART OF #79 CABLE NOT ORDERABLE	
W70	1000211323	Wire GND - - - EP93C	
Z41	1000366596	Screw Socket Head M5x0.8Px12L Hex Socke	Bolts used to connect the console to the console mast.
Not Shown	1000211360	Screw SH M8X1.25PX20L MT HS SSTSUS304	Discontinued - Entertainment-See Entertainment Master on TV product page
W28	1000346760	Ipod Extend Wire 180(APPLE MFI5120	Discontinued - Discontinued - Replaced with third generation cable