




DRAWING NO	TM759-AG7		
PART NAME	Grip Set;Semi-Assy-L		
PART NO	1000450780	REV	A
APPROVE	SuYehua	DATE	2022.08.09




DRAWING NO	TM759-SF01		
PART NAME	Part Explosive Diagram		
PART NO	1000478849	REV	A
APPROVE	SuYehua	DATE	2022.08.09



DRAWING NO	TM759-AG8		
PART NAME	Grip Set;Semi-Assy-R		
PART NO	1000450781	REV	A
APPROVE	SuYehua	DATE	2022.06.01




DRAWING NO	TM759-SF02		
PART NAME	Part Explosive Diagram		
PART NO	1000478850	REV	A
APPROVE	SuYehua	DATE	2022.06.01



DRAWING NO	TM501-AN13		
PART NAME	Safetv Switch Set		
PART NO	1000231246	REV	B
APPROVE	XUBW	DATE	121321

備註：組裝后總長度（含夾子/鑰匙圈）860~870mm
Note:Length of assembly(Chip/Key ring)860~870mm



Bubble #	OME Part #	Part Description
1	1000438475	TV Support Bracket Set;;;Vulcan&Cyclops
1	1000510413	TV Support Bracket Set;;;Vulcan&Cyclops
AB1	1000490631	Frame Set;;;painting;;Black2;TM759K;DM51
AB5	0000089488	Elastomer Set;Running Deck;mid;;TM501;;
AB5	1000208940	Extrawork;Elastomer;Running Deck;Nai Ri
AC1	1000490668	Console Mast Set-Exreawork;;left;Screen
AC2	1000490676	Console Mast Set-Exreawork;;right;Screen
AG1	1000490695	Handlebar Set;;;painting;202020;Graphite
AG4	1000434025	Fixing Plate;Arm Rest;;painting;;Black C
AG4	1000485338	Fixing Plate;Arm Rest;;painting;;Black C
AG7	1000450780	Hand Pulse Grip Set;Semi-Assy;left;;;TM
AG8	1000450781	Hand Pulse Grip Set;Semi-Assy;right;;;T
AH2	1000490684	Elevation Supt Rack Set;;;painting;;Blac
AM1	1000510410	DRIVE MOTOR SET;Semi-Assy;;;;;TM759K-1US
AN1	1000510412	Console Base Set;Semi-Assy;;;;;TM759K-1U
AN101	1000438386	Overlay set;;;;;Cyclops;
AN13	1000231246	Safety Key Set;;;TM501-1US;;
AN29	1000231246	Safety Key Set;;;TM501-1US;;
AN29	1000474430	Safety Key Set;;;Switch wire + Keychain;
AR1	1000386064	Roller Set;Front;Diam.60x678;;TM703
AR1	1000503911	Roller Set;Front;Diam.60;;JR01
AR1	1000503911	Roller Set;Front;Diam.60;;JR01
AR2	1000404982	Roller Set;Rear;Diam.60.0x660.0;Zinc;;TM
AR2	1000503912	Roller Set;Rear;Diam.60;;JR02
AR2	1000503912	Roller Set;Rear;Diam.60;;JR02
AT1	1000488790	TV Rack Set;;;painting;;Flat Black;HURES
AU0	1000490709	Idler Set;Semi-Assy;;;;;TM759K;
B27	1000471197	running deck-Extrawork;;;Beeswax;Chyuan
B27	1000471198	running deck-Extrawork;;;Chyuan Sheng;6
B28	000820-E2	Decorate Plate;Deck;right;PP;Black;;TM42
B30	1000490659	Fixing Plate;Frame;L;painting;DM515 matt
B33	1000490661	Fixing Plate;Frame;R;painting;DM515 matt
B34	1000412624	Cushion;Deck;;NBR;Black;f30x37;TM501;
B35	1000393329	Screw;Flat Head;M8x1.25Px37L;Machine Thr

Bubble #	OME Part #	Part Description
B37	004926-00	Nut;Nylon;M8x1.25P;;Black Zinc;
B39	000821-E2	Decorate Plate;Deck;left;PP;Black;;TM42;
B43	1000476936	Fixing Plate;Side Rail2;;Zinc Plate;;;TM
B44	004539-AC	Screw;Socket Head;M8x1.25Px25L;;Hex Sock
B45	1000490654	Stopper Fixing Plate;Side Rail;;painting
B47	1000476930	Attached Plate;Elastomer;;Zinc Plate;30.
B48	0000095667	Foot Pad Set;;back;;;3/8"-16UNC;TM512;
B52	004364-AC	Screw;BH;M5x12L;CT;PH;-;BED;-;FX9;
B56	1000304478	Screw;Button Head;M5x0.8Px12L;;Phillip;S
B57	020340-00	Screw;Button Head;M5x0.8Px15L;;Phillip;;
B58	1000230700	SCREW;TRH;4x15L;SM;PH;CHM;POT;
B59	094924	KSS HC-OR
B60	0000089800	Washer;Disc Spring;Diam.6.4xDiam.14.0x1.
B61	064674-A	Washer;Flat;f6.2xf13.0x1.0t;Black Zinc;
B62	004720-00	Screw;Button Head;M8x1.25Px20L;;Hex Sock
B63	1000386014	Screw;Socket Head;M6x1.0Px90L-20;;Hex So
B66	004617-00	Screw;Button Head;Diam.4x15L;Sheet Metal
B66	022463-00	Screw;TRH;4X15L;SM;PH;;;POT
B70	004616-00	Screw;Button Head;Diam.4x12L;Sheet Metal
B71	1000490664	Stopper;;;painting;;Black2;TM759K;DM515
c08	1000459277	Magic Wire;;250m/Roll;;
G17	005130-00	Washer;Flat;Diam.8.4xDiam.15.5x1.6T;;Chr
G18	1000410042	Screw;Socket Head;M8X1.25PX70L;;Hex Sock
G27	1000304478	Screw;Button Head;M5x0.8Px12L;;Phillip;S
G31	1000448662	Key CON Wire;;Right;;;22AWG;350+400mm;TK
G32	1000448661	Key CON Wire;;Left;;;22AWG;350+400mm;TKP
H08	1000402674	SLEEVE;;;Anti-rust oil coating;TM703;Di
H08	1000509709	SLEEVE;;;Anti-rust oil coating;TM759K;D
H09	1000402676	Screw;Socket Head;M12x1.75Px40L;Machine
H10	1000402675	Bearing;Dry;SF-1;F26mmFxF20mmDxF18mmdx8.
H13	020477-A	Washer;Flat;Diam.12.5xDiam.23.0x2.0T;;Bl
H15	004928-00	Nut;Nylon;M12x1.75P;;Black Zinc;
H17	005200-A	WASHER;FLT;F18.2XF30.0X1.0T;TFN;;
H19	005125-00	Washer;Flat;Diam.10.2XDiam.20.0X1.0T;;Bl

Bubble #	OME Part #	Part Description
H20	004942-00	Nut;Nylon;M10x1.5P;;Black Zinc;
JD09	1000465035	MCB;;;;;A3-V001;;;;AC 1.5KW;110V;VAVE
JD09	1000466888	MCB;;;V009;;;JTM1500 110V MCB
L01	1000227025	Transport Wheels;;;NYLON PA6;;;TM445-1US
L06	1000214660	Pillar;;;45#;Black Zinc;TM424;F16x68.5;
L07	1000099219	Open-Type Pin;R-Type;Nominal diameterf3.
M02	1000410139	Lift Motor;AC;110V;700lbs;;94MM;236MM;6P
M02	1000422215	Elevation Motor Set;Semi-Assy;;;110V;;;
M09	1000303167	Screw Sleeve;Motor;;NYLON PA6;Black;;TM4
M10	020152-00	Screw;Hex Head;3/8-16UNCX50L-20L;;Hex;;B
M11	1000448779	Filter;;20A;;BF1103-20A-04(3.2);120/250V
M12	004934-00	Nut;Nylon;3/8-16UNC;;Black Zinc
M13	005125-00	Washer;Flat;Diam.10.2XDiam.20.0X1.0T;;Bl
M15	004362-00	Screw;Button Head;M4x0.7Px10L;;Phillip;;
M16	020340-00	Screw;Button Head;M5x0.8Px15L;;Phillip;;
M17	1000466533	Fan;Cooling;12VDC;0.13A;HDB8025L;700mm/J
M18	035695-AB	Screw;Button Head;M4x0.7Px30L;;Phillip;;
M25	005125-00	Washer;Flat;Diam.10.2XDiam.20.0X1.0T;;Bl
M26	1000104691	Screw;Socket Head;M10x1.5Px30L;;Hex Sock
M27	020423-A	Washer;Spring Lock;F10.2XF19.0X2.0T;;Bla
M34	1000466845	Elastomer;Motor;;NR;RED;Rubber;TM747;T=6
M39	1000398324	PLASTIC LINER;Incline Motor;down;;;?10x?
M39	1000521387	Bearing;Dry;LIFT MOTOR;Down;?10x?12x13L;
N01	1000434088	Face Plate Cover;Console;up;ABS/PA757;;;
N02	1000441806	Face Plate Cover;Console Base;down;ABS/P
N03	1000434090	Kettle Rack;Console;left;TPR+PP;Gray/804
N04	1000434091	Kettle Rack;Console;right;TPR+PP;Gray/80
N05	1000441848	Cover;Console Base;Left-Outer;ABS/PA757;
N06	1000441849	Cover;Console Base;Right-Outer;ABS/PA757
N07	1000434101	Back Cover;Console;;ABS/PA757;;;TM747;
N08	1000438760	Safety Key Cover-Extrawork;upper coverr;
N09	1000441821	Arm Rest;;left;ABS/PA757;BL/Black C;;TM7
N10	1000441822	Arm Rest;;right;ABS/PA757;BL/Black C;;TM
N13	1000441820	Cover;Console Base;Right-Inner;ABS/PA757

Bubble #	OME Part #	Part Description
N14	1000441819	Cover;Console Base;Left-Inner;ABS/PA757;
N15	1000438457	Clip;Open-Type;;;;TM737
N20	1000434093	Decorate Cover;Safety Key;down;ABS PA757
N21	1000436965	Fixing Rack;Safety Switch;;SPHC;2.0T;BED
N22	020340-00	Screw;Button Head;M5x0.8Px15L;;Phillip;;
N60	1000448702	Ground Wire;;;;;14AWG;2000;(KST,MDFNYD2-
N61	1000387231	Console connected wire;;;;;22AWG;1100mm;
N62	1000451649	TV Signal Wire;;;;;2300;HD-SDI;38P008-S
N63	1000367380	Digital COMM Wire;;;;;2200;MOLEX,50-70-
N64	1000435138	Safety Switch Cable;;;;;700;H6630R1-04+
N65	1000444864	Console Power Wire;;;;;22AWG;2400;TKP,H6
N67	1000399413	Clamp;;Color:Pantone Q510;;;
N68	001676-00	Wire Buckle;TM06
N70	0000093244	Screw;Button Head;4x8L;Sheet Metal Thre
N80	1000444480	Safety Key Cover;;down;ABS PA757S;;;TM74
N81	004635-A	Screw;Button Head;Diam.3x7L;Sheet Metal
Not Shown	1000490706	Hardware Set;Semi-Assy;;;;;TM759K;
Not Shown	ZMS4018038	TM Antislip 3M Tape; 4"x 6" Strips
P01	1000317921	Power Switch;;W/O Light;125V/250V;20A;R2
P02	003347-00	Overcurrent Breaker;20A;125V/250V;;
P03	1000501726	Fixing Plate;Power Cord;;painting;DM515
P04	002127-A	BS Connect Wire;;;Black;;;;60(KST,FDFNYD
P05	1000471465	PowerSocket,,150+250+80,,,,SS-3B-1.5-6.3
P07	065248-A	TV Signal Connector;F FEMALE;F-A028-NBX7
P08	0000093219	Boot;;;PVC;RED;VCP 100030R;EP79;
P09	020491-00	WASHER;TOOTH;Diam.5.3XDiam.10.0X0.6T;;WZ
P10	004889-00	Nut;Hex;M5x0.8P;SS41;White Zinc;
P101	1000438494	TV Signal Wire;;;;;500(38P008-S1T7-Ax2
P102	1000438496	TV Power Extension Wire;;;;;500(TKP,H6
P11	001597-A	GROMMET;NYLON;WHT
P11	1000503080	Moveable Bushing;Free shape;;;Black;10 m
P111	004475-00	Screw;Socket Head;M8x1.25Px15L;;Hex Sock
P112	004356-AB	Screw;Button Head;M4x0.7Px12L;;Phillip;;
P113	004539-AC	Screw;Socket Head;M8x1.25Px25L;;Hex Sock

Bubble #	OME Part #	Part Description
P114	004527-AC	Screw;Socket Head;M8x1.25Px35L;;Hex Sock
P115	0000093219	Boot;;;PVC;RED;VCP 100030R;EP79;
P12	003378-00	Ferrite Choke;Zn-Mo;;;T31x19x16-C;ENCORE
P12	1000531596	Ferrite Choke;Zn-Mo;31.5x19.5x15.5(MAX);
P13	003569-A	TV Signal Connector;;F-A005;Jhong Yan
P14	1000206783	E-PORT Wire;;;;;;;;;400(AMP,569532)x2;
P15	1000462417	Power board set;Semi-Assy;;;;;TM747;
P16	065248-A	TV Signal Connector;F FEMALE;F-A028-NBX7
P17	1000220132	SCREW;BH;M5X0.8PX40L;MT;PH;SST;-;
P18	1000216278	Connect Wire;;;;;;;;;100L;;
P19	1000454648	Network Signal Wire;;;;;;;;;2300;COMMSCOPE
P20	1000454709	Ethernet Connector;;;8PIN;;KINSUN 3101B10300;Yell
P21	1000461146	Fixing Base Set;Power supply;;;TM747;;
P22	1000226831	GND;;;Yellow/Green1;;14AWG;200;Diam.5.0
P24	1000437486	Filter Power Wire;;;;;;;;;300+320;KST,RVS3-
P25	1000444863	MCB power wire;;;;;12AWG/14AWG;360+570;T
P26	020340-00	Screw;Button Head;M5x0.8Px15L;;Phillip;;
P28	053427-A	CTRL Keypad GND;;L/R;;;;;200(KST,FDFNYD2
P29	056225-A	Ferrite Choke;Snap-Together;;Lian Cih;FH
P29	1000452650	Ferrite Choke;Snap-Together;;Lian Cih;FH
p30	1000473306	Extensional Power Wire;US;;;110V;;;20
P31	1000468190	Ferrite Choke;;;Lian Cih;FH1300B;JIS us
Q01	1000368949	Cover;Motor;up;ABS FA3001;Black 7C;;TM70
Q03	1000381919	Velcro;Motor Cover;50x30mm;;;black;
Q05	1000441824	Rail;Frame;;PVC;;;TM759;
Q06	1000368952	Decorate Cover;Frame;right;ABS/PA757;;Bl
Q07	1000368956	Decorate Cover;Frame;left;ABS/PA757;;Bla
Q09	1000332723	Decal Plate;Side Cover;left;ABS/PA757K;;
Q10	1000441845	Cover;Consoel Mast;Right-Outer;ABS/PA757
Q11	1000441846	Cover;Consoel Mast;Left-Outer;ABS/PA757;
Q12	1000368960	End Cap;Frame;Right-Rear;;;Black 7C;TM70
Q13	1000368958	End Cap;Frame;Left-Rear;ABS/PA757;;Black
Q15	004617-00	Screw;Button Head;Diam.4x15L;Sheet Metal
Q15	022463-00	Screw;TRH;4X15L;SM;PH;;;;POT

Bubble #	OME Part #	Part Description
Q16	080875	Screw;TRUSS Head;Diam.4x10L;Thread Cutti
Q17	1000390589	Cushion;Side Rail;;EPDM;;;TM724-1US;
Q17	1000390768	Cushion;Side Rail;;SBR;;650x23x6.0T;TM70
Q18	1000228690	SCREW;BH;M8X1.25PX30L;;;HS;G12.9;BZN;
Q19	1000393374	Screw;Button Head;M5x0.8P;11.5L;Machine
Q22	004640-A	Screw;Button Head;F4x35L;Sheet Metal Thr
Q23	018627-A	Washer;Flat;Diam.5.2xDiam.10.0x1.0T;;Bla
R02	1000503275	Treadmill Belt-Extrawork;;;Beeswax;GeoTu
R03	1000340397	Belt;POLY-V;;250-J12;Halftone;GATES
R03	1000499688	Belt;POLY-V;;250-J12;acron;
R04	004542-00	Screw;Socket Head;M10x1.5Px110L;;Hex Soc
R06	005125-00	Washer;Flat;Diam.10.2XDiam.20.0X1.0T;;Bl
R07	005048-00	Washer;Flat;Diam.8.2xDiam.15.0x1.2T;;Bla
R08	0000083680	Washer;Spring Lock;8.0x13.0x1.5T;;BED;
R09	004523-00	Screw;Socket Head;M8x1.25Px40L-30L;;Hex
T02	0000084630	Safety Switch;;;R13-69;TM501
TS05	1000490216	TV Rack Plate;;L;painting;;Flat Black;RB
TS06	1000490218	TV Rack Plate;;R;painting;;Flat Black;RB
U14	1000304308	Spring;Extension;F3.0XF23.6X67L;SWPB;Bla
U16	004539-AC	Screw;Socket Head;M8x1.25Px25L;;Hex Sock
U17	005042-00	Washer;Flat;Diam.8.2xDiam.30.0x2.0T;;Bla
U18	005238-00	Washer;Disc Spring;Diam.8.2xDiam.16.0x1.
V05	1000443730	Model Label;Motor Cover;;;PU;;;TM759
V10	1000462388	Direction Label;;;Black Word/White Base;
V11	1000462389	Direction Label;;;Black Word/Red Base;;R
Z02	005130-00	Washer;Flat;Diam.8.4xDiam.15.5x1.6T;;Chr
Z03	0000086277	Screw;TH;M8x1.25Px20L;;Hex Socket;;BED;B
Z04	0000093382	Screw;Socket Head;M8x1.25Px20L;;Hex Sock
Z08	1000093965	Screw;Socket Head;M8x1.25Px70L-30L;;Hex
Z09	005048-00	Washer;Flat;Diam.8.2xDiam.15.0x1.2T;;Bla
Z10	0000083680	Washer;Spring Lock;8.0x13.0x1.5T;;BED;
Z11	020101-AB	Screw;Socket Head;M8x1.25Px55L-30L;;Hex
Z19	004368-AB	Screw;BH;M5x20L;;PH;;CHM;;;
Z19	004399-00	SCREW;BH;M5X0.8PX20L;;PH;;CHM;;