

CARDIO CONSOLE CODES

General Information:

- Press the UP Speed/Load key [▲], the numeric [#] key, and then press the [ENTER] key once to enter this mode. Pressing [▲] or [▼] forwards or backs up through the selections. Pressing [ENTER] then selects that item. Enter values then press the [ENTER] key again to store the value.
- Once in console codes mode, pressing [▲] [▼] forwards or backs up through the selection, pressing [ENTER] then selects that item. Pressing [CLEAR] exits any of the special access modes.
- Pressing [CLEAR] twice will exit the Console Service Mode.

Workout Default Console Codes:

[▲] [2] [ENTER] "DEFAULTS"

- [▲] [ENTER] "ENTER WT XXX"
- [▲] [ENTER] "ENTER LEVEL 1 TO 20"
- [▲] [ENTER] "ENTER TIME 5 TO 99"
- [▲] [ENTER] "ENTER AGE 10 TO 99"
- [▲] [ENTER] "CHR PERCENT XX"
- [▲] [ENTER] "ENTER SPEED XX.X"
- [▲] [ENTER] "QUICK SPEED XX.X"

NOTE: SEVERAL CODES MAY BE INCLUDED IN THE CONSOLE CODES LIST THAT DO NOT APPLY TO THE TREADCLIMBER® FUNCTIONS.

[▲] [3] [ENTER] "CUSTOMIZE"

- [▲] [ENTER] "MAX TIME"
- [▲] [ENTER] "COOL DOWN"
- [▲] [ENTER] "CHANGE UNITS"
- [▲] [ENTER] "HR INPUTS"
- [▲] [ENTER] "SELECT STATS"
- [▲] [ENTER] "LANGUAGE"
- [▲] [ENTER] "UPPER CONTRAST ADJ"
- [▲] [ENTER] "LOWER CONTRAST ADJ"
- [▲] [ENTER] "MAX SPEED"
- [▲] [ENTER] "ENABLE MAG KEY"
- [▲] [ENTER] "AUTO STOP"
- [▲] [ENTER] "SET DEFAULTS"

[▲] [4] [ENTER] "MACHINE STATUS"

- [▲] [ENTER] " RUN HOURS"
- [▲] [ENTER] " WORKOUTS"
- [▲] [ENTER] " DISTANCE"
- [▲] [ENTER] " CONSOLE VERSION" "Displays Console Version #"
- [▲] [ENTER] "DEVICE TYPE" "Displays Machine Type"
- [▲] [ENTER] " TM DRIVE VER"
- [▲] [ENTER] " MAINT HOURS"

Workout Default Console Codes Continued...

[▲][5][ENTER] " R AND D"

[▲] [ENTER] " PROGRAM LOOP"

[▲] [ENTER] " COM TIMEOUT"

[▲][6][ENTER] " DIAGNOSTIC "

[▲] [ENTER] "DISPLAY TEST"

[▲] [ENTER] "KEY TEST"

[▲] [ENTER] "SERIAL PORTS"

[▲] [ENTER] "A SENSOR B"

[▲] [ENTER] "I/O TEST"

[▲] [ENTER] "BUS VOLTS"

[▲] [ENTER] "TREADLE CENTER"

[▲] [ENTER] "TREADCLIMBER"

[▲][7][ENTER] " MAINTENANCE LOGS "

[▲] [ENTER] "ERROR LOG"

[▲] [ENTER] "MAINT HOURS"

[▲] [ENTER] "QA ID"

[▲][8][ENTER] " CHANGE MACHINE" [ENTER]

For Treadmill Devices, the selections are:


[▲] [ENTER] "TREADCLIMBER"

[▲] [ENTER] "T916"

[▲] [ENTER] "T914"

[▲] [ENTER] "TC/TM CONFIG RQD"

TC9.16 Service Screen Overview



Notes

- To access a specific service menu, enter the key sequence shown under the menu title (the '^' character indicates the speed UP key).
- Navigation through the various service screens is accomplished using the treadle min/max keys or the speed up/down keys.

Kevin Andrews
Rev 1.0
10/26/05