



LCD 12.1 ENTERTAINMENT SYSTEM


LCD-0101-02

LCD-0102-02

LCD-0201-02

LCD-0202-02

END OF LIFE



Customer Support Services
PARTS MANUAL

rev 09 May 2011


LCD 12.1-02 ENTERTAINMENT SYSTEM

Contents

EXPLODED ASSEMBLY	3
LCD COMPONENTS	4
REMOTE CONTROL	5
CONSOLE SUPPORT MOUNTING HARDWARE	6
STAIR CLIMBER MOUNTING HARDWARE	7
CROSS-TRAINER (BLACK) MOUNTING HARDWARE	8
CROSS-TRAINER (SILVER) MOUNTING HARDWARE	9
TREADMILL (BLACK) MOUNTING HARDWARE	10
TREADMILL (SILVER) MOUNTING HARDWARE	11

LCD 12.1-02 ENTERTAINMENT SYSTEM


Exploded Assembly



Description	Part No.
LINE-CORD: 125V; 10A; DOMESTIC B	0017-00003-0963
POWER-SUPPLY: AC-TO-DC; 12V 6' CORD	0017-00003-0967
POWER-SUPPLY: AC-TO-DC; 12V 10' CORD	0017-00003-0970
LINE-CORD: 250V; 10A; EUROPEAN B	0017-00003-0964
LINE-CORD: 250V; 10A; BRITISH B	0017-00003-0965
LINE-CORD: 250V;10A; AUSTRALIAN B	0017-00003-0966
COAX CBL-ASSY	AK32-00020-0002

LCD 12.1-02 ENTERTAINMENT SYSTEM

LCD Components




LCD 12.1-02 ENTERTAINMENT SYSTEM

Remote control


Remote Assembly Stealth Gray

Type Of Cord	Complete Assembly	Remote Only
Black Coiled Cord	AK32-00162-0002	AK32-00118-0000
Gray Coiled Cord	AK32-00162-0001	AK32-00118-0001
Gray Straight Cord	AK32-00162-0000	AK32-00118-0002




LCD 12.1-02 ENTERTAINMENT SYSTEM

Upright and Recumbent Bikes *Mounting Hardware*




LCD 12.1-02 ENTERTAINMENT SYSTEM

Stair Climber Mounting Hardware



LCD 12.1-02 ENTERTAINMENT SYSTEM


Cross-Trainer (Black) Mounting Hardware



LCD 12.1-02 ENTERTAINMENT SYSTEM


Cross-Trainer (Silver) Mounting Hardware

OK62-01265-0000 BRKT: REMOTE; 93X/95Xi



LCD 12.1-02 ENTERTAINMENT SYSTEM

Treadmill (90T, 91T) Mounting Hardware



LCD 12.1-02 ENTERTAINMENT SYSTEM

Treadmill (Silver) Mounting Hardware

