



How to Re-wax your Phenolic treadmill deck

Important: If your phenolic treadmill deck is worn down through the black coating, it cannot be re-waxed.

Materials Needed:

- [TM003](#) NGS Deck Wax; (1lb bag is enough for three treadmill decks.)
- Clothing iron-never to be used again on clothing
- roll of 2" masking tape.

Instructions:

1. Apply a strip of masking tape to both long sides of the deck approximately two inches in from the edges of both long sides. The purpose of the tape is to make sure the wax is applied only to the area of the deck under the running belt.
2. Heat the clothes iron to its maximum temperature. Put a handful of TM003 NGS Deck Wax on the center surface of the deck and place the preheated iron on the top of it until the wax melts.
3. Spread the deck surface over the deck surface by pushing the melted wax across the deck with the iron. Add more wax as needed until the entire top surface of the deck is covered with melted wax.
4. Apply enough wax until the top of the deck has a thin layer of wax. When applying wax, more is not better. The area should have a thin layer of wax only, with no pooling of wax on the deck surface.
5. Repeat steps 1-4 on the "B" side of the deck.