



* Press inward slightly so that the notch or opening on the shroud locks onto the mount.

Both halves of the foot cover must fit over the ridge on the foot. The outer half (B) must fit over the flange on the inner half (A), and its tabs must fit into the notches on the weight tower upright.