

## Procedure 7.7 - Replacing the Circuit Breaker

### Removing the Circuit Breaker

1. With the lift set at level 1, turn off the EFX 544 with the circuit breaker, then unplug the power cord from the wall outlet.

#### **WARNING**

Before continuing with this procedure, review the Warning and Caution statements listed in Section One, Things You Should Know.

2. Remove the front cover as described in Procedure 7.1.
3. Remove the wires from the circuit breaker.
4. Remove the screws that secure the circuit breaker to the EFX 544.

### Replacing the Circuit Breaker

5. Make sure that the new circuit breaker is set to OFF. Position the breaker so that the label is facing up, then install the screws that mount the circuit breaker to the EFX 544.
6. Reconnect the loose wire connected to the power entry module to the line terminal of the circuit breaker. Reconnect the loose wire connected to the lower PCA to the load terminal.
7. Re-install the front cover as described in Procedure 7.1, then check the operation of the EFX 544 as described in Section Four.