

Procedure 7.21 - Replacing a Stairarm Pivot Block

1. The stairarm pivot has been made an integral part of the stairarm assembly. The pivot block is no longer individually replaceable. The stairarm is provided with a pivot block that is permanently attached to the stairarm. If the pivot block is defective, the stairarm must be replaced per Procedure 7.24.