

## Procedure 7.19 - Replacing a Handlebar

1. Set the on/off switch in the "off" position, then unplug the power cord from the wall outlet.
2. Remove the four screws that fasten the handlebar to the upper pivot arm.

**Diagram 7.14 - Handlebar Mounting**



3. Set the replacement handlebar in its mounting position. Hand start the four mounting screws. Center the handlebar in the indented area of the upper pivot arm. Torque the four mounting screws to 300 inch pounds.