
## **Procedure 6.5** — Replacing the Circuit Breaker


1. Set the treadmill circuit breaker in the "off" position and unplug the treadmill's line cord from the AC outlet.


## Diagram 6.4 — Circuit Breaker Mounting Panel



- 2. Disconnect all of the wiring from the circuit breaker.
- 3. Remove the circuit breaker mounting screws. Remove the circuit breaker from the treadmill.
- 4. Set the replacement circuit breaker in its mounting position. Fasten the circuit breaker to the circuit breaker mounting panel using the screws removed in step 4.
- 5. Connect the wiring to the circuit breaker per Diagram 6.5.

## Diagram 6.5 — Circuit Breaker Wiring





- 6. Set the circuit breaker mounting panel in it's mounting position. Fasten the circuit breaker mounting panel to the treadmill using the screws removed in step 2.
- 7. Check treadmill operation per Section 3.