



Date Revision
 04.19.00 Revised 48=48A

Model: 3007F / 3007A
 Pic: AD-F001A

SportsArt FITNESS

3007 / HR

12/5/2002

Bbl#	Description	Qty	Part #
1	Display assembly	1	3007-01
*	Display w/ HR	1	3007-01A
2	Pedestal	1	3007-02
3	Display back panel	1	3007-03
4	Ribbon cable - Upper	1	3007-04
5	Display post cover	1	3007-05
6	Handrail - right	1	3007-06
7	Handrail - left	1	3007-07
*	Handlebar grip only (short)	2	3007-07A
8	Frame	1	3007-08
9	Deck	1	3007-09
10	Walking belt	1	3007-10
11	Rear end cap - left	1	3007-11
11A	Rear end cap - right	1	3007-11A
12	Rear roller	1	3007-12
13	Spacer block	2	3007-13
14	Rear support w/ leveler	2	1200-14
15	Handrail side bracket	2	3007-15
16	Guide roller	2	1096-13
17	Front roller	1	3007-17
18	Landing strip (deck trim)	2	3007-18
19	Hood bracket	4	3007-19
20	Power switch plate	1	3007-20
21	ON/OFF switch	1	ONSW-01
22	Transformer	1	3007-22
23	Hood	1	3007-23
*	Hood - HR style	1	3006-23
24	End cap - Front	2	3007-24
25	Capacitor	1	3007-25
26	Drive belt - 320J	1	3007-26
27	Drive motor	1	3007-27
*	Motor brushes	1	3007-27A
28	Optical switch & wheel - Kit	1	3007-28K
29	Encoder wheel	1	3007-29
30	Drive board	1	3007-30
*	Fuse - 0.2A, drv brd, 5x20 mm	1	F02S-01
31	Fuse - 2A, elevation	1	F2AT-01
32	Fuse holder	1	FSHR-01
33	Fuse - 15A, main	1	F15F-01
34	Power cord	1	1200-47
35	Inductor - 6.2 mH	1	3007-35
36	Heat sink plate	1	3007-36
37	Terminal	1	1096-21
38	Ribbon cable - Lower	1	1200-51
39	Lift assembly	1	3007-39
*	AC motor only	1	1096-44A
40	Transport wheel	2	3007-40
41	Wheel axle	1	3007-41
42	Lift motor capacitor	1	1096-42
43	Steel gear	1	1096-41
44	Nylon gear	1	1096-40
45	VR (potentiometer) assembly	1	1096-39
46	Cover	1	1096-38

Bbl#	Description	Qty	Part #
47	Finger guard	2	3007-47
48A	Safety key	1	1200-02
49	Handlebar bracket tube	1	3007-49

PARTS NOT SHOWN OR DISC

*	Owners manual	1	3007-OM
*	HR receiver	1	5002-36
*	Label - Frame rail	2	3007-55
*	Eprom	1	3007-EP