




StairMaster 4000PT Drive Hub Assembly & Components



Drive Hub Assembly Components

Ð	SM030	Thrust Bearing, each (four required)
18	SM031	Drive Sprocket, Left
19	SM032	Drive Sprocket, Right
20	SM033	Snap Ring, Drive Shaft
2	SM034	Thrust Washer, each (eight required)
2	SM035	Drive Shaft w/ Sprocket
23	SM039	Hub