


Magnetic Key Problems

Ergo bar problems include the Ergo bar itself and the magnetic key.

Rust on the magnetic key can cause intermittent "POWER LOSS" and "DRIVE ERROR" messages to appear on the console. The magnetic key should be inspected weekly for signs of rust forming on the magnet. Replace the magnet if it looks anything like the rusted magnet in the picture.



The magnetic's logo "S" should be over the Ergo bar magnetic pick-up bracket.

If the magnetic key is not being used, the Ergo PCB and CHR PCB must be grounded.

Wiring Schematics

Use the schematics on the following pages to assist you in isolating and correcting electrical and electronic problems.