

- Press **Stop Belt** and – simultaneously to decrease the configuration.
4. When finished, press **Select** or **Enter** to store the configuration.
  5. Press **Stop**, **Faster**, and **Slower** simultaneously to leave Service Mode.

### ClubTrack Plus Models

1. Press **Stop**, **Faster**, and **Slower** simultaneously to enter Service Mode.
2. Continue to press **Next** until **NVR Load** appears, then select it.
3. Press **Exit** to leave Service Mode.

## Viewing the Drive Revision Number

### ClubTrack Models

1. Press **Stop**, **Faster**, and **Slower** simultaneously to enter Service Mode (screen will display P000).
2. Press **Stop Belt** and **Down** simultaneously to view the code revision number.
3. Press **Stop**, **Faster**, and **Slower** simultaneously to leave Service Mode.

### ClubTrack Plus Models

1. Press **Stop**, **Faster**, and **Slower** simultaneously to enter Service Mode.
2. Continue to press **Next** until **Drive Revision** appears, then select it.
3. Press **Return** to return to the Service screens.
4. Press **Exit** to exit Service Mode.

## Viewing the Controller Revision Number

### ClubTrack Models

1. Press **Stop**, **Faster**, and **Slower** simultaneously to enter Service Mode (screen will display P000).
2. Press **Stop Belt** and **Down** simultaneously to view the code revision number.
3. Press **Stop**, **Faster**, and **Slower** simultaneously to leave Service Mode.