

The Elliptical Edge records and stores usage data which may be used as an aid in maintaining the unit and diagnosing malfunctions. The Service Settings Mode lets you view this usage data, as well as software version numbers and the serial number and date of manufacture for the unit.

To enter the Service Settings Mode:

1. Press and hold the "Enter", "0" and "2" keys at the same time.
2. While continuing to hold the "Enter" and "0" keys, release the "2" key. The unit will beep once, and the message "Service Settings" will show in the upper information display.
3. Release the "Enter" and "0" keys.

Once the unit is in the Service Settings Mode, use the keypad to view service settings, service messages, or system measurements.

The following stored data may be viewed while in the Service Settings Mode:

ITEM	DESCRIPTION
Display Version	Version of software currently installed in the display.
LCB Version	Version of software currently installed in the Load Control Board.
Serial#	Serial number of the unit.
Manufacture Date	Unit manufacture date (displayed as DDMMYY).
Workout Hours	Total number of operating hours accumulated on the unit to date.
Workout Distance	Total number of distance units accumulated on the machine to date. Distance units are displayed in either miles or kilometers (depending on the "Units" selection (English or Metric) chosen in "Display Settings").
Battery Hours	Total number of hours the battery has been used under power (displayed in thousands of hours). Need to reset to zero when battery replaced.
Last Keystrokes	Displays the last five keys pressed prior to a software or system failure.