




Manager Mode

After having used your **Star Trac 4500 treadmill** for several workouts, you may wish to specially customize your treadmill by changing some of its settings.

To engage Manager Mode:

1. Press and hold the “ 0 ”, “ 1 ” & “ START ” keys together. While holding the “ 0 ” & “ START ” keys down, release the “ 1 ” key only.
2. The display will beep and display **Manager Mode** momentarily, then **UNITS** will be displayed.

Once the treadmill is in Manager Mode, you may use the following keys:



INCLINE KEY: Displays the next or previous parameter.




SPEED KEYS: Allows the variable to be changed within the parameter.



ENTER KEY: Saves the value if changed in the EPROM (software).
Note: ENTER KEY must be pressed, for each value changed.



STOP KEY: Exits Manager Mode and restarts the treadmill with a “warm start.”



0 – 9 KEYS: Enters new parameter values. If **UNITS** parameter is displayed, key **5** starts DISPLAY TEST and key **8** starts MOTOR TEST.



HEART KEY: When pressed will automatically display manufactures default value.
Note: ENTER KEY must be pressed, to save the default values if changed.

Manager Mode

The following parameters may be changed using the previous keys:

Parameters	Lowest Value	Highest Value	Option 1	Option 2	Default Value	Meaning
UNITS	---	---	English	Metric	English	English= units of lbs., miles, hours, minutes Metric= units of kg., km, hours, minutes.
MN SPD	0.1	2.5	English=0.5	Metric=1.0	0.5	Minimum speed in MPH or KM/HR
MX SPD	5.0	20.0	English=10.0	Metric=20.0	10.0	Maximum speed in MPH or KM/HR
EL OPT	---	---	ON	OFF	ON	Turns the elevation system ON or OFF.
TIME	5	99			99	Maximum time in minutes allowed for program, including warm-up/cool-down.
OP HRS	0	0	---	---	6,553.5	Total operating hours
DIST	0	0	---	---	65,635	Total treadmill miles (Units=English) or kilometers (Units=Metric)
WEIGHT	0	399	---	---	155	Defaults (to user), typical weight in lbs/kg depending on what setting (UNITS= English or Metric)
SER NO	0	0	---	---	65,535	Treadmill serial number.
LANG	---	---	---	---	English	Language in English, Dutch, German, Portuguese, Spanish, Swedish, or Italian.
ENTRY	---	---	Units	Tenths	Units	This variable changes the starting speed in Units or Tenths