GZFM6007.7

Key	Part Number	Description	Qty
	0	FREE MOTION CALF	0
	0	5/03 SMITHFIELD	0
	0	COMPANY 14	0
1	GZ5071	TOWER	1
2	GZ5038-02	ACCESS COVER	1
3	GZ5088	BASE FRAME	1
4	GZ5686	SEAT RAIL	1
5	GZ1021-01	RIVET	24
6	GZ5684	SEAT FRAME	1
7	GZ3248-01	WEIGHT GUIDE	1
8	GZ5108-05	SEAT	1
9	GZ3190-02	LEFT STABILIZER COVER	1
10	GZ3190-01	RIGHT STABILIZER COVER	1
11	GZ5006	RIGHT STABILIZER	1
12	GZ5005	LEFT STABILIZER	1
13	GZ5108-04	BACKREST	1
14	GZ1732	HAND GRIP	2
15	GZ5033	TOP WEIGHT	1
16	GZ3204	BASE FRAME COVER	1
17	GZ1003-01	PULLEY	5
18	GZ9601	FOOT PLATE	2
19	GZ1193	TOP WEIGHT BUMPER	1
20	GZ1044	RELEASE HANDLE	1
21	GZ1013-04	3/8" X 2" BOLT	6
22	GZ3007	WEIGHT STACK SUPPORT	2
23	GZ1001	WEIGHT BUMPER	2
24	GZ3091	DOUBLE CABLE GUIDE	3
25	GZ1024	TOP WEIGHT BUSHING	1
26	GZ1069	3/8" SERRATED LOCK WASHER	4
27	GZ3072-03	LARGE WEIGHT	15
28	GZ3072-02	SMALL WEIGHT	9
29	GZ1014-05	3/8" X 2.25" BOLT	1
30	GZ3073-01	LONG PIVOT ROD	1
31	GZ3073-02	SHORT PIVOT ROD	2
32	GZ1100	SMALL BUMPER	6
33	GZ5020-54	RELEASE CABLE HOUSINT	1
34	GZ1011-01	1" BEARING	8
35	GZ1047	1/4" SET SCREW	4
36	GZ3205-02	RIGHT BASE COVER	1
37	GZ3205	LEFT BASE COVER	1
38	GZ1020	SMALL BUSHING	2
39	GZ1028	5/16" NUT	10
40	GZ1052	1" NYLON WASHER	7
41	GZ1018-01	1" RETAINER RING	6
42	GZ1083	3/8" FINE NUT	2
43	GZ1014-01	3/8" X 1" SCREW	6
44	GZ1082	3/8" NUT	4
45	GZ1009-01	1/2" X 1" BOLT	12
46	GZ1063	ROD END	2
47	GZ1085	5/8" LOCK WASHER	4
48	GZ3102	SINGLE CABLE GUIDE	6
49	GZ5020-08	CABLE ASSEMBLY	1
50	GZ1015-01	5/16" X 1" SCREW	6
51	GZ1013-03	3/8" X 1" BOLT	6
52	GZ1656	WEIGHT PIN	1
53	GZ1012-07	3/8" X 1/2" SCREW	12
54	GZ1007	3/8" NYLON LOCKNUT	7
55	GZ1074	3/8" WASHER	4

56	GZ5044	PIVOT MOUNT	2
57	GZ1517	FLOOR BUMPER	3
58	GZ1084	5/8" NUT	4
59	GZ1504	TRIM	1
60	GZ1677	SPRING	1
61	GZ1988	NYLON SEAT ROLLER	3
62	GZ1740	1/2" x 2 1/2" SHOULDER BOLT	3
63	GZ1110	RELEASE PIN	1
64	GZ1755	ENDCAP SET SCREW 1"	2
65	GZ1756	GRIP HANDLE COLLAR 1"	2
66	GZ1761	#10 SCREW SET CUP	8
67	GZ3242-10	SHORT THREADED CABLE END	1
68	GZ9359	RELEASE CABLE HOUSINT	1
69	GZ3242-02	LONG THREADED CABLE END	1
70	GZ1111	LARGE BUMPER	2
71	GZ1013-12	3/8" X 1 1/4" BOLT	2
0	0	NON-ILLUSTRATED PARTS	0
		WHAT PART IS NEEDED?	
#	GZ7003	10 POINT WARNING DECAL	1
#	GZ7003FR	10 POINT WARNING DECAL	1
#	GZ7003G	10 POINT WARNING DECAL	1
#	GZ7003IE	10 POINT WARNING DECAL	1
#	GZ7003IT	10 POINT WARNING DECAL	1
#	GZ7003SP	10 POINT WARNING DECAL	1
		WHAT PART IS NEEDED?	
#	GZ7004	INTERNAL WARNING DECAL	1
#	GZ7004FR	INTERNAL WARNING DECAL	1
#	GZ7004G	INTERNAL WARNING DECAL	1
#	GZ7004IE	INTERNAL WARNING DECAL	1
#	GZ7004IT	INTERNAL WARNING DECAL	1
#	GZ7004SP	INTERNAL WARNING DECAL	1
		WHAT PART IS NEEDED?	
#	GZ7005	CAUTION MOVING PART DECAL	1
#	GZ7005FR	CAUTION MOVING PART DECAL	1
#	GZ7005G	CAUTION MOVING PART DECAL	1
#	GZ7005IE	CAUTION MOVING PART DECAL	1
#	GZ7005IT	CAUTION MOVING PART DECAL	1
#	GZ7005SP	CAUTION MOVING PART DECAL	1
		WHAT PART IS NEEDED?	
#	GZ7026	DECAL,SELECTOR PIN INSERT	1
#	GZ7026FR	DECAL,SELECTOR PIN INSERT	1
#	GZ7026G	DECAL,SELECTOR PIN INSERT	1
#	GZ7026IT	DECAL,SELECTOR PIN INSERT	1
#	GZ7026SP	DECAL,SELECTOR PIN INSERT	1
#	GZ7036	SEAT POSITION CALF DECAL	1
#	156809	BAG WARNING DECAL	2
		WHAT PART IS NEEDED?	
#	GZ7544	USER'S MANUAL	1
#	GZ7544FR	USER'S MANUAL	1
#	GZ7544G	USER'S MANUAL	1
#	GZ7544IT	USER'S MANUAL	1
#	GZ7544SP	USER'S MANUAL	1

EXPLODED DRAWING—Model No. GZFM6007.7

R0108A