DIAGNOSTICS: SYSTEM TEST – FITLINXX TEST MODE

This test will give information concerning whether there is a Fitlinx system connected to the treadmill. The following is a list of the current information that can be seen:

```
NONE
NULL -  T-XX   R-XX
OFF -   T-XX   R-XX
ON  -   T-XX   R-XX
WAIT -  T-XX   R-XX
```

The "T-XX" is the last transmitted message to the C-safe card.
The "R-XX" is the last received message from the C-safe card.

Press the 'CLEAR' key to exit the Fitlinx test and return to the System Test Menu.