

Diagnostics - Entry

DIAGNOSTICS ENTRY - TR9000HR

Diagnostics is entered by holding the 'PAUSE' key when power is applied or by holding the 'PAUSE' key and pressing the 'CLEAR' key twice from any state. The unit will take approx. 3 to 4 seconds to enter Diagnostics.

DIAGNOSTICS ENTRY - T9i

Diagnostics is entered by holding the 'JOG' key when power is applied or by holding the 'JOG' key and pressing the 'STOP' key twice from any state. The unit will take approx. 3 to 4 seconds to enter Diagnostics.

FIRST STATE ON BOTH UNITS

On entry to this state, the message "SERVICE MENU" will appear.

"USE ARROW KEYS TO SCROLL THROUGH LIST".

Using any of the arrow keys will allow you to scroll through four main categories.

SYSTEM TEST
INFORMATION
MAINTAINANCE
CONFIGURATION

Press the 'ENTER' key to enter the desired category.

