

Life Fitness 9100 Series Heartrate and Telemetry Equipped Treadmills How To...REMOVE AND REPLACE THE ANTI-STATIC CORDS

Tools Required: Needle-nose pliers

ATTENTION: THE 9100 TREADMILL HAS TWO ANTI-STATIC CORDS. ONE IS LOCATED BEHIND/BETWEEN THE STRIDING BELT, THE OTHER BENEATH. EITHER OF THESE TWO MAY BREAK OR REQUIRE REPLACEMENT.

Step 1

Turn the power OFF at the switch and by unplugging the unit at the electrical outlet.

Step 2

Carefully tilt the unit on its side.

NOTE: INSPECT THE AREA BETWEEN THE STRIDING BELT FOR DEBRIS.

Step 3

Both ANTI-STATIC CORDS are equipped with an eyelet on one end and a spring on the other. Unhook the spring end of the CORD from the bracket first, to avoid snap back, and then unhook the eyelet end.

Step 4

Install the new ANTI-STATIC CORD eyelet end first.

Step 5

Reverse Steps 1 and 2 to restore unit to operation.