



How to upgrade your MCB to LST882 or LST926 MCB

- 1. Install the current wax lift board. Use provided hardware to mount Wax board to new MCB.**
- 2. Remove and Discard Speed Sensor, Thermal Sensor, Data Cable and Capacitor Board from old unit.**
- 3. MCB upgrade includes four new cables to be installed.**
- 4. Plug cable AK58-00042-0003 Drive Motor Extension cable into P1 connector (on MCB). Plug other end to Drive motor. Plug cable AK58-00035-0001 to 2-pin connector on cable AK58-00042-0003.**
- 5. Plug cable AK58-00035-0001 Motor Controller Interface cable into P9 connector (on wax board). Next plug cable AK58-00639-0000 cable to 6-pin connector on cable AK58-00035-0001.**
- 6. Plug cable AK58-00639-0000 Wax/Lift-to-DSP Interface Adapter cable into P5 connector (on MCB).**
- 7. Plug cable AK58-00263-0000 Jumper cable plugs into P8 connector (on MCB).**
- 8. If you are working on a Nextgen treadmill. Plug cable AK58-00637-0000 AC Power Adapter cable into P7 connector (on MCB).**
- 9. Use UPS label to return old MCB to National Gym Supply for store credit.**