

CLUBTRACK Clubtrack Controller Configuration CP--

Treadmill	Configuration No.	Speed Range	Grade
No Configuration	CP--	-----	---
No Configuration	CP0	-----	---
Clubtrack Hd	CP03	1-12	15%
Clubtrack Plus Hd	CP03	1-12	15%
MedTrack SR60 Hd	CP03	1-12	15%
MedTrack CR60 Hd	CP01	.6-7.2	15%
ST 55	CP07	.8-9.6	25%
ST 65	CP07	.8-9.6	25%
Clubtrack 3.0	CP05	1-10	15%
Clubtrack Plus	CP05	1-10	15%
Medtrack R60	CP05	1-10	15%
Not Used	CP02	1.5-18	15%
Not Used	CP04	.8-9.6	15%
Not Used	CP06	.6-7.2	25%
Not Used	CP08	1-12	25%
Not Used	CP09	1.5-18	25%
Clubtrack 510	CP10	1-10	12%
Clubtrack 612	CPO3	1-12	15%

If CP-- is shown in the controller display, then the N-V RAM has been reinitialized. A new configuration must be selected for the controller to operate. To reinitialize the N-V RAM, you must

Enter the service mode by simultaneously pressing **Stop Belt, Faster** and **Slower**.
Press **Stop Belt** and **Cool Down**.

To select the CP number: Clubtrack

1. Enter the service mode by simultaneously pressing **Stop Belt, Faster** and **Slower**.
2. Select the configuration number by holding down **Stop Belt** and depress **Input +** or **Input -** until the correct configuration number appears in the display.
3. Press **Select** to store the configuration.
4. Exit the service Mode by simultaneously pressing **Stop Belt, Faster** and **Slower**.

To select the CP number: **Clubtrack Plus HR**

1. Enter the service mode by simultaneously pressing **Stop Belt, Faster** and **Slower**.
2. Press the Menu button 3 times.
3. Press F3 Select configuration
4. Simultaneously press **Stop Belt, Faster** and **Slower** to exit the Service Mode and save the configuration.

CP--

CP-- is an indication that the controller has lost its configuration in memory. The configuration may be able to be restored by selecting the CP code again on the Control Panel. See page 4-30 and 4-31 of the service manual.

If this does not correct the problem then the controller will have to be replaced.

