

Life Fitness Cross-Trainers 90X, 93X, 95Xe, and 95Xi

How To... Replace the Main Shroud

Special Service Tools Required: NONE

1. Remove the four Phillips screws (two on each side) securing the Main Shroud to the Drive Frame Assembly.
2. Remove the Main Shroud by lifting them straight up.
3. Install the Main Shroud in reverse order.

Note: Make sure the Main Shroud fits into the grooves in the Lower Shroud Panels.

