

## **Life Fitness 9100 Series Heartrate and Telemetry Equipped Treadmills** **How To...REMOVE AND REPLACE THE HANDLEBAR**

**Tools Required:** Phillips screwdriver, hex key wrench set, socket and ratchet set

---

### **Step 1**

Turn the power OFF at the ON/OFF switch and by unplugging the machine at the electrical outlet.

### **Step 2**

Remove the DISPLAY CONSOLE (See "How To...").

### **Step 3**

Loosen, but do not remove, the two BOLTS securing the base of the RIGHT HANDRAIL to the Treadmill FRAME.

### **Step 4**

Remove the six SCREWS securing the HANDLEBAR to the two HANDRAILS. On models equipped with Lifepulse sensors, withdraw the HANDLEBAR WIRE HARNESS with the 4 PIN CONNECTOR from the user LEFT HANDRAIL. Lift out and remove the HANDLEBAR.

### **Step 5**

Grasp the new HANDLEBAR, and with the WIRE HARNESS to the left on models equipped with Lifepulse sensors, route the WIRE HARNESS through the opening in the LEFT HANDRAIL, exiting alongside the other WIRE HARNESS. Align the three holes in the HANDLEBAR FLANGE with those in the LEFT HANDRAIL and re-install the SCREWS. Repeat on the right side.

### **Step 6**

Reverse Steps 1 through 4 to return the Treadmill to operation.

