

Life Fitness 9100 Series Heart Rate and Telemetry Equipped Treadmills
TROUBLESHOOTING GUIDE

Symptom: Display Does Not Illuminate or Respond To Input

Malfunction	Probable Cause	Corrective Action
<p>Display does not illuminate when machine is powered on.</p>	<p>Insufficient power source.</p> <p>Pinched wire connection</p> <p>Loose connection at display console or control board.</p> <p>Faulty CPU control board.</p> <p>Faulty display console.</p>	<ul style="list-style-type: none"> <input type="checkbox"/> Plug treadmill into a dedicated 120V, 20 amp circuit <input type="checkbox"/> Turn power off for 30 seconds. Turn power on and within 30 seconds of turning on press "9-0-9" on the keypad. <input type="checkbox"/> Check all electrical connections. <input type="checkbox"/> Check all electrical connections. <input type="checkbox"/> Secure connections at display console and control board. <input type="checkbox"/> Switch CPU control board with another Life Fitness model 9100 treadmill if available. <input type="checkbox"/> Replace CPU control board. <input type="checkbox"/> Switch display console with another Life Fitness model 9100 treadmill if available. <input type="checkbox"/> Replace display console. <p>Call Life Fitness Customer Support Services 847-451-0036 or 1-800-351-3737</p>